

SNL plummer block housings solve the housing problems

Revised edition



Contents

Made by SKF[®] stands for excellence. It symbolises our consistent endeavour to achieve total quality in everything we do. For those who use our products, "Made by SKF" implies three main benefits.

Reliability – thanks to modern, efficient products, based on our worldwide application know-how, optimised materials, forward-looking designs and the most advanced production techniques.

Cost effectiveness – resulting from the favourable ratio between our product quality plus service facilities, and the purchase price of the product.

Market lead – which you can achieve by taking advantage of our products and services. Increased operating time and reduced down-time, as well as improved output and product quality are the key to a successful partnership.



1 Product information	3
Fewer bearing replacements and less maintenance	3
Plummer block housings have much to offer	3
SNL plummer block housings have more to offer	3
One basic design – many variants	4
Costs and risks – at a low level	6
High performance for all sectors	8

2 Recommendations

Bearing arrangement design	10
Bearings on adapter sleeves on smooth shafts	10
Bearings on adapter sleeves on stepped shafts	11
Bearings on withdrawal sleeves on stepped shafts	12
Bearings on cylindrical seatings on stepped shafts	13
Standard seals	14
Special seals	21
End covers	22
Locating rings	22
Axial displacement using CARB bearings in	
SNL housings	24
Application advice for trouble-free operation	26
Lubrication	28
Mounting	30
Mounting SNL housings with double-lip seals	34
Mounting SNL housings with V-ring seals	36
Mounting SNL housings with felt seals	38
Mounting SNL housings with labyrinth seals	40
Mounting SNL housings with taconite seals	42
Mounting SNL housings with oil seals	44
3 Product data	46
Designations and housing data	46
Designations	46
Load carrying ability	47
Product tables	50
SNL plummer block housings for bearings	
on adapter sleeve	50
SNL plummer block housings for bearings	
with cylindrical bore	62
Sealing arrangements for SNL plummer block housings	72

Other products for trouble-free operation......76

Customer benefits

2 Recommendations

Page 10

3 Product data

Page 46

Fewer bearing replacements and less maintenance

Plummer block housings SNL plummer block have much to offer

The main benefit of split plummer block housings is their easy installation; pre-assembled shafts can be mounted in them. When the housing bases are attached to the base plate it is then only necessary to place the housing caps in position and to tighten the attachment bolts to complete the installation.

Split plummer block housings available on the market are mainly intended for self-aligning ball bearings, spherical roller bearings and CARB® bearings of ISO Dimension Series 02, 03, 22, 23 and 32. They can often be fitted with various different seals. Many designs and variants of split plummer block housings are available making the use of tailored housings unnecessary and thus enabling cost effective bearing arrangements to be made.

For many years SKF has been one of the leading producers of split plummer block housings - synonimous with operational reliability, quality and versatility.

housings have more to offer

SKF has developed the SNL plummer block housings to be the first choice for design, quality and economy. This enables customers to keep a step ahead.

SNL plummer block housings enable the full service life potential of the incor16porated bearings to be exploited

with less need of maintenance. This supports user efforts to further reduce maintenance costs. Among other characteristics the housings are very stiff, making them insensitive to uncontrolled and excessive tightening of the attachment bolts.

Another benefit is the choice of oil or grease lubrication for the bearings housed in SNL plummer blocks. A range of efficient seals for oil lubrication and rough environments make for trouble-free operation.

Customer benefits

One basic design – many variants

SNL plummer block housings are primarily intended for self-aligning ball bearings, spherical roller bearings and CARB bearings. The housings are designed on a "building block" principle. This enables a more generous choice of bearing, shaft mounting, seals and type of lubrication. Stocking is also simplified.

A building block system

The basis of the SNL plummer block housing system consists of a number of housings of the same design but in different sizes. By combining these housings with the different standard seals a wide variety of housing variants, all belonging to the standard range, can be supplied to cover the majority of demands for plummer blocks for shafts having diameters of 20 to 160 mm, inclusive. The standard range also covers other variants, for example, housings with drilled and tapped holes for lubrication nipples or condition monitoring sensors. Housings are also available for bearings for larger shaft diameters (\rightarrow page 79).

SNL plummer block housings are made of grey cast iron and demonstrate high strength. Should, however, this strength be inadequate, dimensionally equivalent plummer block housings of spheroidal graphite cast iron can be supplied.

2 Recommendations

Page 10

Several sealing options

An important advantage of the SNL plummer block housings is that they can be fitted with a variety of seals. The standard seals supplied by SKF comprise double-lip seals, V-ring seals, felt seals, labyrinth seals and heavy-duty "taconite" seals as well as end covers. Other standard seals are also available for SNL housings, but these are supplied together with the housings as the housing has to be modified to take them. These are oil seals and heavy-duty axial taconite seals.

SNL plummer block housings are fully interchangeable with the earlier SNH housings. Their dimensions conform to ISO 113:1994.

Painting system

SNL plummer block housings are painted as standard in accordance with ISO 12944-2, environmental Class C2. Black colour: RAL 9005.



Page 46

SNL plummer block housing with sealing options **Customer benefits**

2 Recommendations

Page 10

3 Product data





Design characteristics

Costs and risks – at a low level

SNL plummer block housings have several advantages, such as the high load carrying capacity and machining quality as well as the wide variety of sealing alternatives with the following design and performance characteristics.

2 Recommendations

Page 10



Stiff design

The housing base is reinforced with ribs and extra material surrounding the holes for the attachment bolts in order to provide improved seating on the base plate. The attachment bolts can be preloaded to give correct location and prevent deformation of the housing base and bore.



Page 46



Excellent heat conduction

The web (rib) reinforcement of the housing base enlarges the contact area between base and base plate and allows for an improved heat flow from the bearing outer ring to the base plate. The bearings will run 5 to 10 % cooler than in other housings.



Drilled and tapped hole with nipple

SNL housings have a drilled and tapped hole as standard in the cap. The hole is protected by a plastic plug. The nipple is supplied, together with a nipple protecter, with the housing (packed inside). If the application is such that relubrication is required it is only necessary to screw the nipple into the hole and lubricant can be supplied to one side of the bearing.

Stiff design Insensitive to uncontrolled tightening of the attachment bolts, low operating temperatures Low bearing temperatures, high speed operation Excellent heat conduction possible with oil lubrication, long relubrication intervals, long service life, low lubricant consumption Relubrication facility as standard Drilled and tapped hole with nipple Caps and bases Avoids mixing of caps and bases, permits traceability individually marked Indications for holes to Simple and easy adaptation of standard housing to take other components individual applications, easy attachment of condition monitoring equipment Simple mounting Simple and reliable mounting and maintenance Additional seals Several sealing options, long bearing service lives



Caps and bases individually marked The housing base and cap are matched during manufacture and are not interchangeable with the caps and bases of other housings. To prevent mixing caps and bases when mounting several housings, the same consecutive number is marked on the cap and base of each individual housing.

5KF

Design characteristics

2 Recommendations

Page 10

3 Product data

Page 46



Indications for holes to take other components

SNL housings can be fitted with sensors serving permanently installed condition monitoring equipment based on vibration measurements. The positions where holes can be drilled to take these sensors are indicated on the housing.



Simple mounting

In order to simplify mounting and make alignment more accurate, cast indications, which are vertical to the centre of the bore of the housing, are provided on the end faces as well as on the side faces of the housing base. Mounting instructions, included with each seal pack, give valuable tips.





1

Additional seals

Two new seal designs have been developed specifically for SNL housings. One is intended for difficult conditions which call for a robust seal which can be relubricated and the other is for high speeds and oil lubrication.



All branches of industry

High performance for all sectors

High load carrying capacity and reliability, easy maintenance, the variety of applications and robust designs have made SKF housings a must. The most important sectors of industry and their demands are listed below.

2 Recommendations

Page 10

3 Product data

Page 46

One important reason for the popularity of SKF housings is the increased awareness of the impact of enhanced quality on the cost of a machine and its total life.

Industry

- Pulp and paper
- Metallurgical
- Mining and construction
- Fluid machinery
- Materials handling
- · Handling systems

Demands

- · Long service life
- Robust design
- Long relubrication intervals
- Ready for relubrication
- Condition monitoring facilities
- Avoid risk of mixed caps
- Fast and easy mounting and dismounting



All branches of industry

2 Recommendations

Page 10

3 Product data















Page 3

2 Recommendations

Types of arrangement

3 Product data

Page 46

Bearing arrangement design

SNL plummer blocks can be used with self-aligning ball bearings, spherical roller bearings or CARB bearings fitted on smooth (plain) or stepped shafts; the bearings can be mounted on adapter or withdrawal sleeves or directly on cylindrical shaft seatings. The plummer blocks can also be used with other bearing types of suitable Dimension Series.

1. Bearings on adapter sleeves on smooth shafts

Advantages

- Drawn round bar (tolerance h9) can be used without machining
- Maximum shaft strength as there is no weakening by shoulders or reliefs
- Bearings can be mounted at any position on the shaft
- Mounting force, i.e. the force required to drive up the bearing on to the sleeve, is some 40 % smaller than with other bearing arrangements on sleeves because friction occurs only in one contact

 Bearing radial clearance can be adjusted within certain limits during mounting to meet application demands

Applications

- Bearing arrangements for relatively long shafts where more than two bearings are required for support
- Bearings arrangements where machine components are mounted using wedging or tensioning components which do not require the shaft to be machined
- Bearing arrangements where the final position of the bearing cannot be accurately determined



Bearings on adapter sleeves on smooth shafts

2 Recommendations Types of arrangement

Page 3

2. Bearings on adapter sleeves on stepped shafts

Advantages

- The bearing position on the shaft is accurately determined by the abutment ring
- Other components on the shaft can be axially located by the bearing on its sleeve via spacer sleeves
- Easy dismounting as the bearing inner ring is in contact with the abutment ring
- Bearing radial clearance can be adjusted within certain limits during mounting to meet application demands

Applications

- Bearing arrangements at shaft ends
- Bearing arrangements where frequent mounting and dismounting are required

Bearings on adapter sleeves on stepped shafts



3 Product data

Page 46

SKF

Page 3

3. Bearings on withdrawal sleeves on stepped shafts

Advantages

- The bearing position on the shaft is accurately determined by the shaft shoulder
- Other components on the shaft can be axially located by the bearing on its sleeve via spacer sleeves
- Easy dismounting using a withdrawal or hydraulic nut
- Bearing radial clearance can be adjusted within certain limits during mounting to meet application demands

Applications

- Bearing arrangements at shaft ends
- Bearing arrangements where frequent mounting and dismounting are required

Bearings on withdrawal sleeves on stepped shafts









3 Product data

Page 46

2 Recommendations

Types of arrangement

Page 3

4. Bearings on cylindrical seatings on stepped shafts

Advantages

- The axial load carrying capacity of the bearings (in both directions) is not limited by a sleeve
- The residual bearing internal clearance is determined by the tolerance of the shaft seating so there is no danger of radially preloading the bearing during mounting
- The bearing position on the shaft is accurately determined by the shaft shoulder
- The bearing can be supported by other components via spacer sleeves
- The shaft diameter at the bearing position is maximised

2 Recommendations

Types of arrangement

3 Product data

Page 46

Applications

- Bearing arrangements where large numbers of bearings have to be mounted
- Bearing arrangements where large shock loads can occur

Bearings on cylindrical seatings on stepped shafts



Page 3

Standard seals

An important advantage of SNL plummer block housings is that they can be fitted with different types of seal. The standard seals available from SKF are split double-lip seals and felt seals, one-piece V-rings, labyrinth seals and the heavy-duty "taconite" seals. The

2 Recommendations

Standard seals

seals are easy to install and are supplied separately.

All the standard seals as well as the seals for use with oil lubrication are presented in **Table** 1, which gives a comprehensive overview of the seal types, their design features and their suitability for various operating conditions. Detailed information on the

3 Product data

Page 46

various standard and special seals including properties and availability will be found on pages 16 to 21.

Seal selection

						Table 1
-						
	TSN G	TSN A	TSN C	TSN S	TSN ND	TSN TURU ¹⁾
Internal conditions						
Temperature, °C	-40 to +100	-40 to +100	-40 to +100	-50 to +200	-40 to +100	-40 to +200
Peripheral speed, m/s	up to 8	up to 7 above 7 ²⁾	up to 4	++	up to 12	++
Misalignment, degrees	0,5 to 1	1 to 1,5	up to 0,5	up to 0,3	up to 0,5	up to 1
Relubrication grease	4 m/s ³⁾	++ ⁴⁾	-	+	+	
Oil lubrication	-			-	-	++
Low friction	+	++	-	++	+	++
Axial shaft displacement	++	-	++	+	+	-
Vertical mounting	+	++ ⁵⁾			-	
Replacement	++	-	+	-	-	-
External conditions						
Dust	++	+	+	+	++	-
Sand	++	+	-	+	++	+
Grit	+	-	-	+	++	+
Sharp objects, chipping splinters etc	+		+	++	++	++
Liquids when sprayed	+	+	-		++	-
Direct sunshine	+		++	++	++	++

Symbols:

++ very suitable - limited suitability

+ suitable -- unsuitable

 $^{1)}$ Delivered as a complete unit only, i.e. housing with seals $^{2)}$ When V-ring axially supported $^{3)}$ When using housing with grease escape hole (suffix V) $^{4)}$ If appropriate components are used: ASNA .. V $^{5)}$ When the V-ring of the lower seal is mounted inboard

Page 3

Permissible shaft speeds for rubbing seals

2 Recommendations

Standard seals

3 Product data

Page 46

					Table 2
	C design felt seals		A design V-ring seals	G design double-lip sea	Is
Shaft diameter	Guideling for stand	e values for lard seals o	the permissible sh f design	aft speed ¹⁾	
d _a , d _b	C ²⁾	А	G		
mm	r/min				
20 25 30	3 820 3 060 2 550	6 680 5 350 4 460	7 640 6 110 5 090		
35 40 45	2 180 1 910 1 700	3 820 3 340 2 970	4 360 3 820 3 390		
50 55 60	1 530 1 390 1 270	2 670 2 430 2 230	3 060 2 780 2 550		
65 70 75	1 180 1 090 1 020	2 060 1 910 1 780	2 350 2 180 2 040		
80 85 90	960 900 850	1 670 1 570 1 490	1 910 1 800 1 700		
95 100 110	800 760 690	1 410 1 340 1 220	1 610 1 530 1 390		
115 120 125	660 640 610	1 160 1 110 1 070	1 330 1 270 1 220		
130 135 140	590 570 550	1 030 990 960	1 180 1 130 1 090		
145 150 155	530 510 490	920 890 860	1 050 1 020 990		
160 165 170	480 460 450	840 810 790	960 930 900		

The speeds are valid when the seals are operated at temperatures between -40 and +100 °C (permissible temperature range). At temperatures outside this range and/or at speeds higher than those given, labyrinth seals should be used.

The guideline values are based on the permissible sliding speed at the seal/counterface contact. However, the permissible shaft speed is determined by the speed rating for the bearing to be used in the housing
 The guideline values are based on a peripheral speed of 4 m/s. Higher speeds are possible, see under "Felt ring seals"

Page 3

Double-lip seals

Double-lip seals (\rightarrow fig 1) are made of polyurethane, a wear-resistant material which has good elastic properties. The seals are split so that they are easy to fit. They are intended for grease lubrication and can be used at peripheral speeds of up to 8 m/s. The permissible angular misalignment is approximately 1° for shaft diameters up to approximately 100 mm and 0,5° for larger sizes. The seal counterface on the shaft should be ground and the surface roughness Ra should not exceed 3,2 µm. The recommended shaft tolerance is h9. When using housings with grease escape hole (suffix V) the speed limit is 4 m/s due to increased pressure on the inner seal lip.

The axial movement of the shaft relative to the housing is not limited when double-lip seals are used.

The double-lip seals are always supplied in packs of two seals. When housings are used at shaft ends, i.e. with one end cover, one of the seals will be left over and can be kept as a spare. The double lip seals are iden-

2 Recommendations

Standard seals

tified by the designation prefix TSN followed by the size identification and the suffix G, e.g. TSN 511 G.

V-ring seals

The V-ring seals (\rightarrow fig 2) consist of a V-ring and a sheet steel sealing washer with vulcanised rubber lip which fits into the sealing groove in the housing. The washer is protected against corrosion. The V-rings are made of nitrile rubber (NBR) and have a slim sealing lip which seals axially against the sealing washer. The V-ring "body", which sits tightly on the shaft and rotates with it, also serves as a flinger. V-ring seals provide efficient sealing even under difficult operating conditions such as high speeds, rough finished shafts etc. They can be operated at peripheral speeds in excess of 7 m/s if the V-ring is prevented from moving or lifting from the shaft by a support ring. Recommended dimensions for appropriate support rings (for axial and radial location) are given in Table 3.

The permissible angular misalignment for V-ring seals is approximately 1,5° for a 50 mm shaft decreasing to

3 Product data

Page 46

approximately 1° for a shaft diameter of 150 mm and above. The axial movement of the shaft relative to the housing is limited to ± 1 mm for shaft diameters up to 65 mm and to approximately $\pm 1,2$ mm for larger shaft diameters.

The V-ring seals are always supplied in packs of two seals. When housings are used at shaft ends, i.e. with one end cover, one of the seals will be left over and can be kept as a spare. The V-ring seals are identified by the designation prefix TSN followed by the size identification and the suffix A, e.g. TSN 511 A.



Page 3

Recommended dimensions for support rings for V-ring seals

2 Recommendations

Standard seals

3 Product data



Shaft	Dimensions						Grub			V-ring
diameter							screw			Designation
d _a , d _b	d ₁	d_2	В	B ₁	B ₂	D	A	G ₁	to DIN 913	
mm	mm								-	-
20	20	27,2	555	8,5	3,5	30	2,5	M3	3×5	CR 400200
25	25	32,1		8,5	3,5	35	2,5	M3	3×5	CR 400250
30	30	37,2		8,5	3,5	40	2,5	M3	3×5	CR 400300
35	35	42,2	5	8,5	3,5	45	2,5	M3	$\begin{array}{c} 3\times5\\ 4\times5\\ 4\times5\end{array}$	CR 400350
40	40	49,1	7	11,5	4,5	53	3,5	M4		CR 400400
45	45	54	7	11,5	4,5	58	3,5	M4		CR 400450
50	50	59,1	7	11,5	4,5	63	3,5	M4	$\begin{array}{c} 4\times5\\ 4\times5\\ 4\times5\\ 4\times5\end{array}$	CR 400500
55	55	64,1	7	11,5	4,5	68	3,5	M4		CR 400550
60	60	69,1	7	11,5	4,5	73	3,5	M4		CR 400600
65	65	74,1	7	11,5	4,5	78	3,5	M4	$\begin{array}{c} 4\times5\\ 5\times6\\ 5\times6\end{array}$	CR 400650
70	70	81	9	15	6	84	4,5	M5		CR 400700
75	75	86	9	15	6	89,5	4,5	M5		CR 400750
80	80	91	9	15	6	94,5	4,5	M5	5×6	CR 400800
85	85	96	9	15	6	100	4,5	M5	5×6	CR 400850
90	90	101	9	15	6	105	4,5	M5	5×6	CR 400900
95	95	106	9	15	6	109	4,5	M5	5×6	CR 400950
100	100	111	9	15	6	115	4,5	M5	5×6	CR 401000
110	110	122,9	10	17,5	7,5	128	5	M6	6×8	CR 401100
115	115	127,4	10	17,5	7,5	133	5	M6	$\begin{array}{c} 6 imes 8\\ 6 imes 8\\ 6 imes 8\end{array}$	CR 401100
125	125	138,1	10	17,5	7,5	143	5	M6		CR 401300
135	135	147,5	10	17,5	7,5	153	5	M6		CR 401300
140	140	152,9	10	17,5	7,5	158	5	M6	$\begin{array}{c} 6 imes 8\\ 6 imes 8\\ 6 imes 8\end{array}$	CR 401400
145	145	158,1	10	17,5	7,5	163	5	M6		CR 401500
155	155	167,5	10	18,5	8,5	173	5	M6		CR 401500
165	165	179,9	10	18,5	8,5	185,5	5	M6	$\begin{array}{c} 6 imes 8\\ 6 imes 8\end{array}$	CR 401700
175	175	189,3	10	18,5	8,5	195	5	M6		CR 401700

Page 3

Felt ring seals

Felt ring seals (\rightarrow fig 3) are simple but efficient seals for use with grease lubrication. They can be operated at peripheral speeds up to 4 m/s. The seals can be used at much higher speeds but at high speeds a small gap will be formed between the felt and the shaft and the seal becomes a nonrubbing gap-type seal. For plummer block housings with bearings on adapter sleeves on smooth shafts the felt ring seals are split. The impregnated felt is inserted in light alloy halfrings. It is only necessary to insert the seals in the grooves in the housing. The rubber O-section cords should be put into the grooves first as they prevent the seal rings from turning.

SNL plummer block housings for bearings mounted on cylindrical seatings on stepped shafts, sizes 205 to 218 inclusive, can also be supplied with felt seals. In this case the seals consist of loose felt strips which can be inserted in the sealing grooves. Before mounting, the FS felt strips should be left to soak for a few minutes in hot oil.

2 Recommendations

Standard seals

For applications with spherical roller bearings or CARB bearings which are to operate at continuously high temperatures up to approximately +250 °C, SKF graphited FSB sealing strips made of aluminium boron silicate can be used. They are suitable for peripheral speeds up to 2 m/s. The strips have been well proven as seals on autoclave trucks. Reference should be made to the publication 4402 "SKF deep groove ball bearings for extreme temperatures cut machine life cycle costs" which will be sent on request.

The permissible angular misalignment is approximately 0.5° . The seal counterface on the shaft should be ground and the surface roughness R_a should not exceed 3.2 µm.

The axial movement of the shaft relative to the housing is not limited when felt seals are used.

The ready-to-mount felt ring seals (in light alloy half-rings) are always supplied in packs of two seals. When housings are used at shaft ends, i.e. with one end cover, one of the seals will be left over and can be kept as a spare. The felt ring seals are identified

3 Product data

Page 46

by the designation prefix TSN followed by the size identification and the suffix C, e.g. TSN 511 C.

The felt ring seals can also be supplied with an FSB insert. The rubber O-section cords are replaced by fluoro rubber O-section cords. These seals are identified by the suffix CB, e.g. TSN 511 CB.



Ready-to-mount felt ring seal

Felt strips



Page 3

Labyrinth seals

Under difficult operating conditions and/or at high speeds the use of labyrinth seals (\rightarrow fig (4)) is recommended. The labyrinth rings are made of steel and have two radially arranged labyrinth steps which form a narrow sealing gap with the housing grooves.

Hollow O-ring cords of silicone rubber (supplied with the seals) ensure that the labyrinth rings, which are mounted with a loose fit, rotate with the shaft. Angular misalignments of the shaft up to approximately $0,3^{\circ}$ are permissible. The operating temperature range for the labyrinth seals is -50 to +200 °C.

When labyrinth seals are used, axial movement of the shaft relative to the housing is not limited. The recommended shaft tolerance is h9.

The labyrinth seals are supplied singly. For bearing arrangements for through shafts it is therefore necessary to order two rings. The labyrinth seal is identified by the prefix TSN followed by the size identification and the suffix S, e.g. TSN 511 S.

2 Recommendations

Standard seals

Taconite heavy-duty seals

Taconite is a very fine-grained mineral which is extremely difficult to seal against. For bearing arrangements which must operate under very arduous conditions such as those encountered in mining, labyrinth seals which can be relubricated are recommended, as grease enhances the sealing effect and extends the serviceability of the seals. SKF has developed two different designs of these heavy-duty seals (which can seal against taconite, hence the name) which can be supplied for use with SNL housings.

The one taconite seal design (\rightarrow fig \bigcirc) is based on a radial labyrinth seal and fits the standard housings. A V-ring seal mounted on the shaft seals against the non-rotating part of the seal, which is inserted in the seal groove and prevents contaminants from penetrating to the bearing when the seal is relubricated. This grease is supplied via a grease nipple in the non-rotating part of the seal. Angular misalignments of the shaft of up to approximately 0,5° are possible. The permissible operating temperature

3 Product data

Page 46

range for the seal is between -40 and +100 °C.

The axial movement of the shaft relative to the housing is limited for this type of taconite seal to ± 1 mm for shaft diameters up to 65 mm and to approximately $\pm 1,2$ mm for sizes up to 100 mm and $\pm 1,5$ mm for larger shaft diameters. The recommended shaft tolerance is h9.

These seals are supplied singly so that for housings used on through shafts, it is necessary to order two seals. The seal is identified by the prefix TSN followed by the size identification and the suffix ND, e.g. TSN 511 ND.

The other design of taconite seal (\rightarrow fig G) is based on a labyrinth seal with the labyrinth stages arranged axially and does not fit the standard housings. The seal is relubricated via lubrication holes and nipples in the housing cap. The positions for the holes are marked by dimples in the casting. The permissible misalignment of the shaft relative to the housing for this seal is approximately 0,5°. The operating temperature range is from



Page 3

-40 to +250 °C. Axial movement of the shaft relative to the housing is also limited. The recommended shaft tolerance is h9.

The modified SNL housings are always supplied together with the seals and are available from size 515-612. The housings with seals are identified by the designation suffix TNC, e.g. SNL 515 TNC or SNL 612 TNC. A housing intended for a shaft end with one seal and one end cover is identified by an additional suffix A, e.g. SNL 515 ATNC. The seal itself is designated TSN .. NC.

A variant of the TNC seal with an additional V-ring can also be supplied. The seal is identified by the letters TNB and can be supplied to order.

2 Recommendations

Standard seals

Seals for oil lubrication

Special seals (oil seals) are required to prevent oil from escaping from the housing when oil lubrication is applied. For SNL housings, SKF has developed the non-rubbing seal of the U design (→ fig 7). These U seals also require modified housings and comprise two parts: one which is stationary and is screwed to the housing and the other which is mounted on the shaft and rotates. A hollow O-ring cord of silicone rubber inserted between the labyrinth ring and the shaft ensures that the ring, which is mounted with a loose fit, rotates with the shaft, and oil cannot escape along the shaft. These oil seals do not limit axial movement of the shaft relative the housing. The recommended shaft tolerance is h9.

The modified SNL housing is supplied together with the seals as a unit. The housings with seals are identified by the suffix TURU, e.g. SNL 524 TURU. Special end covers can be supplied separately on request, designation ASNH .. R. **3** Product data



Page 3

Special seals

Applications where, for some reason or other, the standard seals cannot be used must be fitted with special seals. The SNL housings can be supplied without seals for such applications and are relatively easy to equip with special seals. It is recommended that housings of series SNL 2 are used rather than those of series SNL 5-6 as they have a comparatively larger bore at the shaft entrance. There is therefore more room to accommodate a seal, so that there is more choice as regards seal design.

Special seals are not normally supplied by SKF. Therefore, the relevant housing dimensions are given in **Table 4**.

Sealing groove dimensions

2	Reco	mme	nda	tion	S
Sı	pecial	sea	s		

3 Product data

Page 46

Housing Size	Dimensio A ₃	A ₄	A ₅	A ₆	D _b	D _c
_	mm					
SNL 205	44	5	7,5	10	36,5	44,5
SNL 206-305	54	5	7,5	10	46,5	54,5
SNL 207	58	5	8	11	56,5	64,5
SNL 208-307	61	5	8	11	62	70,5
SNL 209	59	5	9	12	67	75,5
SNL 210	64	5	9	12	72	80,5
SNL 211	69	5	9	12	77	85,5
SNL 212	79	5	9	12	87	95,5
SNL 213	82	5	9	13	92,5	101
SNL 215	87	5	9	13	102,5	111
SNL 216	92	5	9	13	108	116,5
SNL 217	97	5	9	13	112	120,5
SNL 218	112	5	9	13	120	128,5
SNL 505	45	5	7,5	10	31,5	39,5
SNL 506-605	55	5	7,5	10	36,5	44,5
SNL 507-606	59	5	8	11	46,5	54,5
SNL 508-607	62	5	8	11	51,5	59,5
SNL 509	60	5	9	12	56,5	64,5
SNL 510-608	65	5	9	12	62	70,5
SNL 511-609	70	5	9	12	67	75,5
SNL 512-610	80	5	9	12	72	80,5
SNL 513-611	83	5	9	13	77	85,5
SNL 515-612	88	5	9	13	87	95,5
SNL 516-613	93	5	9	13	92,5	101
SNL 517	98	5	9	13	97,5	106
SNL 518-615	113	5	9	13	102,5	111
SNL 519-616	116	6	10	14	131	141
SNL 520-617	131	6	10	14	137,5	147,5
SNL 522-619	143	6	10	14	147,5	157,5
SNL 524-620	151	6	11	15	157,5	167,5
SNL 526	156	6	11	15	167,5	177,5
SNL 528	171	6	11	15	177,5	187,5
SNL 530	189	6	11	15	192,5	202,5
SNL 532	201	6	11	15	202,5	212,5

Table 4

Page 3

End covers

For housings mounted at the ends of shafts, the one opening should be fitted with an end cover which fits into the seal groove (\rightarrow fig 3). Details of the permissible length of the shaft end can be found in **Table 5**. The end covers are of plastic and are suitable for operating temperatures in the range -40 to +110 °C.

At higher temperatures sheet steel end covers should be used instead. These can be cut out from steel sheet and should be inserted with a hollow O-ring cord of silicone rubber in the seal groove in the housing. The relevant seal groove dimensions are given in **Table**

The standard end cover of plastic is designated by the prefix ASNH followed by the housing size identification, e.g. ASNH 511-609.

2 Recommendations

End covers, locating rings

Locating rings

The bearing seating in the housing is sufficiently wide to enable the bearing to be displaced axially. Bearings which are to locate a shaft axially in both directions (locating bearings) must always be fixed axially in position in the housing bore by locating rings at both sides (\rightarrow fig S).

CARB bearings are non-locating bearings and cannot take axial loads. Since axial displacement is accommodated within a CARB bearing (together with any misalignment) it is necessary to locate the outer ring axially in its seating by inserting a locating ring at each side of the bearing.

The locating rings are identified by the prefix FRB followed by figures giving the width/outside diameter in millimetres, e.g. FRB 11.5/100.

3 Product data

Page 46

Housing with end cover



Housing with locating rings at both sides of bearing

Fig 9



Page 3

Premissible length of shaft end

End covers

3 Product data

Page 46

					Т	able 5
Housing Size	Dimensions ba ¹⁾	s b _c	C _a	Widest bearing to fit Designation	housing Dimensi B	ons b _b
-	mm			-	mm	
SNL 205	18	24	25	22205 CC/W33	18	17
SNL 206-305	20	29	32	22206 CC/W33	20	18
SNL 207	23	32	34	22207 CC/W33	23	20,5
SNL 208-307	26 (22)	33	39	22208 E	23	21,5
SNL 209	25	32	30	22209 CC/W33	23	22,5
SNL 210	28 (24)	35	41	22210 CC/W33	23	23,5
SNL 211	30 (25)	37	44	22211 E	25	25
SNL 212	33 (26)	42	48	22212 E	28	27
SNL 213	35 (30)	45	51	22213 CC/W33	31	29,5
SNL 215	37 (30)	47	56	22215 E	31	30,5
SNL 216	39 (33)	50	58	22216 E	33	33,5
SNL 217	40 (35)	52	61	22217 E	36	36
SNL 218	45 (35)	60	65	23218 CC/W33	52,4	44,2
SNL 505	18	24	25	22205 CCK/W33	18	17
SNL 506-605	20	29	32	2305 EK	24	19
SNL 507-606	23	32	34	2306 K	27	21,5
SNL 508-607	26 (22)	33	39	2307 EK	31	24,5
SNL 509	25	32	30	22209 CCK/W33	23	22,5
SNL 510-608	28 (24)	35	41	22308 CCK/W33	33	26,5
SNL 511-609	30 (25)	37	44	22309 CCK/W33	36	29
SNL 512-610	33 (26)	42	48	22310 EK	40	32
SNL 513-611	35 (30)	45	51	22311 EK	43	33,5
SNL 515-612	37 (30)	47	56	22312 EK	46	36
SNL 516-613	39 (33)	50	58	22313 EK	48	38
SNL 517	40 (35)	52	61	22217 EK	36	36
SNL 518-615	45 (35)	60	65	22315 EK	55	42,5
SNL 519-616	47 (40)	61	68	22316 EK	58	46
SNL 520-617	51 (45)	69	70	23220 CCK/W33	60,3	50,2
SNL 522-619	61	75	80	23222 CCK/W33	69,8	55,9
SNL 524-620	65	79	86	23224 CCK/W33	76	60
SNL 526	65	81	90	23226 CCK/W33	80	63
SNL 528	70	89	98	23228 CCK/W33	88	68
SNL 530	80	98	106	23230 CCK/W33	96	74
SNL 532	85	104	114	23232 CCK/W33	104	80

The dimension b_a is determined to suit all appropriate bearings with two exceptions:

 with self-aligning ball bearings of series 12 where the total bearing seating width must be available, the values given in brackets apply
 for non-locating arrangements with the widest bearings, as listed above, which are not mounted centrally in the housing, the value of b_a must be either correspondingly reduced or correspondingly increased

Page 3

Axial displacement using CARB bearings in SNL housings

The permissible axial displacement in a CARB bearing is dependent on the clearance remaining in the bearing after mounting: the larger the residual radial internal clearance, the larger the permissible axial displacement of one ring with respect to the other. This axial displacement reduces the clearance in the bearing until at a given displacement, the clearance disappears altogether or the rollers may start to be exposed at one side of the bearing.

Table Ishows the maximum per-missible axial displacement for eachCARB bearing having Normal initialradial internal clearance when mount-ed normally. It is assumed that there islittle difference in temperature betweeninner and outer ring.

When the rings are displaced a certain distance, the roller and cage assembly will move through half this distance. If the inner ring moves into the bearing, or alternatively, if the outer ring moves out from the bearing the roller and cage assembly can contact the lock nut and locking washer. For bearings of series C 22 K up to and including size 22, therefore, a special

CARB bearing on adapter sleeve



2 Recommendations

Axial displacement

adapter sleeve with a narrow slot and a self-locking KMFE nut must be used to prevent this happening (\rightarrow fig 10). Such sleeves are supplied by SKF and identified by suffix E, e.g. H 311 E.

For bearings of series C 22 K and C 32 K, from size 24 and above, the adapter sleeves are supplied together with a KML nut, indicated by suffix L in the sleeve designation, e.g. H 2324 L.

It should be observed that the possible axial displacement of the shaft relative to the housing may be limited by the type of seal used. **3** Product data

Page 3

2 Recommendations

Axial displacement

3 Product data

Page 46

Table 6

2



Bearing	Housing Size	Axial displacement s ¹⁾ for mounted CARB bearings with initial radial internal clearance Normal
-	_	mm
C 2205 K	SNL 505	2,3
C 2206 K	SNL 506-605	2,3
C 2207 K	SNL 507-606	2,8
C 2208 K	SNL 508-607	2,7
C 2209 K	SNL 509	3,1
C 2210 K	SNL 510-608	2,9
C 2211 K	SNL 511-609	3,5
C 2212 K	SNL 512-610	3,6
C 2213 K	SNL 513-611	3,7
C 2215 K	SNL 515-612	4,4
C 2315 K	SNL 518-615	5,9
C 2216 K	SNL 516-613	4,4
C 2316 K	SNL 519-616	5,7
C 2217 K	SNL 517	5,1
C 2317 K	SNL 520-617	6,5
C 2218 K	SNL 518-615	5,2
С 2220 К	SNL 520-617	5,4
С 2320 К	SNL 524-620	6,8
C 2222 K	SNL 522-619	6,7
C 3224 K	SNL 524	7,8
C 2226 K	SNL 526	8,0
C 2228 K	SNL 528	8,0
C 2230 K	SNL 530	9,3
C 3232 K	SNL 532	10,5

1) s is the maximum permissible displacement of one ring with respect to the other in one direction; the total axial displacement is twice as large

Page 3

2 Recommendations

Trouble-free operation

3 Product data

Page 46

Application advice for trouble-free operation

Condition monitoring is recommended for SNL plummer blocks particularly if they are used on machines where failures would cause production stoppages. The early recognition and trending of the degradation of the machine and machine parts make it possible to analyse the cause and to be able to plan for corrective maintenance actions in good time.

Extensive monitoring experience and a knowledge of the dynamic behaviour of machines, machine components and bearings where there is incipient damage allows SKF to recommend two powerful signal processing techniques which can be used for condition monitoring.

Vibration velocity

The RMS (root mean square) of the velocity of vibrations in the frequency range 10 Hz to 1 kHz has been used with great success to measure phenomena such as imbalance, misalignment, resonance etc. High levels of velocity vibration can be generated by poor machine conditions such as improper clearances, imbalance, misalignment, weak foundations, bent rotors, out-of-round, belt problems or damaged fan blades. The ISO Standard 10816-1:1995 contains recommendations for reference values for the RMS velocity values measured on different classes of machines and machine parts. These recommendations give a clear and quantifiable measure for the changes in machine condition. Vibration velocity expressed as an overall RMS value in the 10 Hz to 1 kHz frequency range provides minimal information on defects in rolling element bearings or gear mesh problems. These types of defect can now be easily detected by enveloped acceleration in the higher frequency ranges.

Enveloped acceleration

Bearing defects can be easily recognised by measurement and analysis of an enveloped acceleration signal of the higher frequencies generated by the impact signals typical of rolling bearing defects and gear teeth problems. This technique has proven to be



Electronic cabinet with built-in MCM[™] units



Multilog on-line system



Microlog – portable data collector and analyser

Page 3

extremely reliable in the detection of incipient bearing defects. The low frequencies generated by imbalance, misalignment etc. are not measured and diagnosed within the enveloped acceleration process.

 Condition monitoring and diagnosis with permanently installed monitoring systems

This type of monitoring makes it possible to check the condition using MCM[™] (Mechanical Condition Monitor) for a single measuring point or the multilog LMU (Local Monitoring Unit) which sequentially monitors several measuring points. The MCM[™] system should be applied were an economical solution is required (e.g. for fans). The measurement output can be directly connected to a control or DCS (Digital Control System). A relay output is also available to shut down the machine or section of the plant.

Measurement points for condition monitoring

2 Recommendations

Trouble-free operation

 Condition monitoring and diagnosis with a portable data collector and analyser

In this case the condition is monitored using a portable data collector/ analyser at appropriate points on the machine. Where a measurement point is difficult to access, permanently installed sensors can be used. These can be connected by cable to a connection box accessible to the data collector.

Condition monitoring of SNL housings

SNL housings have appropriate points for sensors (\rightarrow fig 1). Measurement points 1 and 2 are perpendicular to the shaft and correspond best to ISO 10816-1:1995. Measurement point 3 lies at approximately 45° to the shaft axis. For enveloped acceleration the angle of inclination of the measuring point is of minor importance.

3 Product data

Page 46

Measurement points 2 and 3 should be used on SNL housings where the load acts towards the base plate. Measurement point 1 is intended for when the housing is hung from its support or when the load acts away from the base plate.

For additional information about condition monitoring and the measurement tools and systems available from SKF please contact the SKF application engineering service.



Page 3

Lubrication

SNL plummer block housings are so designed that the bearings in them can be lubricated with grease or oil, although grease lubrication is generally preferable. The lubricant should be selected with reference to the operating conditions. Relevant information will be found in the SKF General Catalogue and other SKF publications.

Grease lubrication

In the majority of applications, the amount of grease applied to the SNL housings when mounting (first fill) or after an inspection is adequate until the next planned inspection.

Certain operating conditions, e.g. high speeds, high temperatures or heavy loads, may mean that more frequent relubrication is necessary. **Table 1** gives guideline values for the grease quantities to be applied for the first fill and for relubrication. Seven markings will be found on the housing cap of which six show where holes can be drilled and tapped to take grease nipples.

There is also a drilled and tapped hole for the grease nipple AH 1/8-27 PTF which is supplied with the housing. This hole is closed by a plastic plug. The two markings at the outer sides of

Lubrication

the central ridge indicate the position for lubrication holes for the seals.

It is recommended that spherical roller bearings having a lubrication groove and three holes in the outer ring (designation suffix E or W33) be lubricated via this feature (\rightarrow fig 2). A hole should be drilled at one of the middle markings on the three bars for this purpose. SNL housings having a drilled and tapped hole in the middle of the cap together with a lubrication nipple can be supplied on request. They are identified by the designation suffix NM, e.g. SNL 511-609 NM.

It should be noted that when spherical roller bearings are to be relubricated via the outer ring, they should be rotated. If outer ring relubrication is not possible or if self-aligning ball bearings or CARB bearings are used the standard grease nipple supplied with the housing should be inserted in the hole provided and used for this purpose (\rightarrow fig 3). If it is desired to use a grease nipple other than that supplied with the housing, adapters are available which make a reworking of the available drilled and tapped hole unnecessary.

Where V-ring seals are used, the efficacy of relubrication can be much improved if an additional V-ring is mounted inside the housing at the side

Lubricating the bearing via the outer ring



Bearing lubrication via the standard nipple

Fig 3



3 Product data

Page 46

Grease quantities

		Table
Housing Size	Grease First fill ¹⁾	quantities Relub- rication
	g	
SNL 205	25	5
SNL 206-305	40	5
SNL 207	50	10
SNL 208-307	60	10
SNL 209	65	10
SNL 210	75	10
SNL 211	100	15
SNL 212	150	15
SNL 213	180	20
SNL 215	230	20
SNL 216	280	25
SNL 217	330	25
SNL 218	430	40
SNL 505	25	5
SNL 506-605	40	5
SNL 507-606	50	10
SNL 508-607	60	10
SNL 509	65	10
SNL 510-608	75	10
SNL 511-609	100	15
SNL 512-610	150	15
SNL 513-611	180	20
SNL 515-612	230	20
SNL 516-613	280	25
SNL 517	330	25
SNL 518-615	430	40
SNL 519-616	480	50
SNL 520-617	630	55
SNL 522-619	850	70
SNL 524-620	1 000	80
SNL 526	1 100	95
SNL 528	1 400	110
SNL 530	1 700	130
SNL 532	2 000	150

¹⁾ Fills approximately 40 % of the free space in the housing Page 3



Housing Size	Dimer J _a	N ₃	α
_	mm		degree
SNL 205	8,5	10	45
SNL 206-305	10	10	45
SNL 207	10	10	45
SNL 208-307	9	10	45
SNL 209	10	10	45
SNL 210	11	10	45
SNL 211	10	12	45
SNL 212	9	12	45
SNL 213	13	12	45
SNL 215	12,5	12	45
SNL 216	14	16	45
SNL 217	17	16	45
SNL 218	20	16	40
SNL 505	8,5	10	45
SNL 506-605	10	10	45
SNL 507-606	10	10	45
SNL 508-607	9	10	45
SNL 509	10	10	45
SNL 510-608	11	10	45
SNL 511-609	10	12	45
SNL 512-610	9	12	45
SNL 513-611	13	12	45
SNL 515-612	12,5	12	45
SNL 516-613	14	16	45
SNL 517	17	16	45
SNL 518-615	20	16	40
SNL 519-616	20	16	50
SNL 520-617	21	16	50
SNL 522-619	21	20	50
SNL 524-620	24	20	55
SNL 526	22	20	55
SNL 528	23	20	50
SNL 530	25	20	55
SNL 532	25	20	60

The dimensions are those recommended when the standard grease nipple AH 1/8-27 PTF is used (supplied with the housing) but can also be applied if nipples having threads R 1/8, KR 1/8 or M 10×1 are used. An adapter is available which fits the SNL standard lubrication hole, designation LAPN 1/8. Using this adapter nipple with thread G 1/4 and grease dispensers, e.g. SKF SYSTEM 24, can be applied.

2 Recommendations

Lubrication

s

Recommended dimensions for grease escape hole

3 Product data

Page 46

where the grease is applied, so that grease can only exit at the opposite side of the housing. For this purpose a set comprising a V-ring and a splash plate, which covers a sector of more than 180° (\rightarrow fig (4), can be supplied. This V-ring and splash plate set is designated by the prefix ASNA followed by the housing size identification and the suffix V, e.g. ASNA 511 V.

Where the bearings are mounted on adapter sleeves, the grease should be introduced at the side opposite to the lock nut of the sleeve. Where housings are mounted at shaft ends, grease should be applied at the end cover side.

Where G or C-design seals are used it should be noted that grease cannot escape via the seals. If frequent relubrication is required when such seals are used, it is advisable to provide the housing with a grease escape hole (\rightarrow fig 5) through which excess grease can escape. Recommended dimensions will be found in **Table 2**. SNL housings with a grease escape hole in the base can be supplied. This housing design is identified by the suffix V, e.g. SNL 511-609 V.

If housings fitted with the G-design double-lip seals are periodically relubricated the seals can only be operated at peripheral speeds up to 4 m/s as otherwise the sealing lips may overheat and wear.

Housing with additional V-ring and splash plate



Housing with grease escape hole



Page 3

2 Recommendations

Lubrication, mounting

3 Product data

Page 46

Oil lubrication

The SNL housings can be used for oil lubrication at relatively high speeds. When using oil, however, the specially developed U-design seals have to be incorporated to avoid oil loss from the housing (\rightarrow fig ()). These seals are described on page 20. In order for these seals to be used the housing must be modified so that SNL housings for oil lubrication are only supplied complete with seals. It is important not to exceed the recommended oil level if leakage is to be avoided (\rightarrow Table (3)).



Housing for oil lubrication

Recommended oil levels for SNL .. TURU plummer blocks of series 5(00). For series 3(00) and 6(00) please contact SKF

											Table 3
Housing Designation	Oil lev 12 min	vel for bea max	rings of s 22 min	series max	232 min	max	222 min	max	C 22 min	max	
_	mm										
SNL 511 TURU SNL 512 TURU SNL 513 TURU	27 23 29	31 27 33	27 22 28	32 28 34			27 23 28	31 27 33	28 23 29	32 26 34	
SNL 515 TURU SNL 516 TURU SNL 517 TURU	24 34 30	29 39 36	23 33 30	29 40 36			23 33 29	28 39 35	24 34 30	29 39 36	
SNL 518 TURU SNL 519 TURU SNL 520 TURU	31 38 34	38 45 42	31 38 34	38 46 42	33 37	37 42	30 38 33	37 45 41	30 35	36 43	
SNL 522 TURU SNL 524 TURU SNL 526 TURU	39 47	47 57	38	48	42 50 54	47 55 59	37 46 50	46 55 59	39 52	48 62	
SNL 528 TURU SNL 530 TURU SNL 532 TURU					46 48 50	52 54 57	44 45 47	52 54 57	40 44	51 57	

The oil level is measured from the base of the housing. Mark the min and max level on the sight glass.

Page 3

Mounting

SNL housings together with SKF bearings are robust and operationally reliable bearing arrangements which have long lives. However, if they are to achieve their full potential and not fail prematurely they must be properly mounted. Incorrect procedures or unsuitable tools can influence life negatively.

Mounting the bearing

The bearings can be mounted either on a tapered seating – normally for SNL housings in the form of an adapter sleeve – or on a cylindrical seating. When a bearing is correctly mounted on a sleeve there will be interference

2 Recommendations

Mounting

fits between the inner ring, sleeve and shaft. The degree of interference is determined by how far the bearing is driven up on the sleeve and either the internal clearance reduction or the axial drive-up distance can be used as a measure. The clearance reduction in spherical roller bearings can be measured using a feeler gauge, or the new SKF drive-up method can be used. Information will be sent on request.

When mounting self-aligning ball bearings having Normal radial internal clearance (which is relatively small) the clearance reduction can be checked by turning and swivelling out the outer ring. When the swivelling out meets a slight resistance, the bearing has a sufficient degree of interference and





Housing	Dimens	J ₇	N ₄	Housing	Dimens	ions	N ₄
Size	J ₆		max	Size	J ₆	J ₇	max
-	mm			-	mm		
SNL 205	152	16	5	SNL 511-609	234	24,5	8
SNL 206-305	172	19	5	SNL 512-610	234	27	8
SNL 207	172	19	5	SNL 513-611	252	29	8
SNL 208-307	188	22	6	SNL 515-612	257	29	8
SNL 209	188	22	6	SNL 516-613	288	33	8
SNL 210	188	22	6	SNL 517	292	33	8
SNL 211	234	24,5	8	SNL 518-615	317	35	8
SNL 212	234	27	8	SNL 519-616	317	35	8
SNL 213	252	29	8	SNL 520-617	348	39	8
SNL 215 SNL 216 SNL 217 SNL 218	257 288 292 317	29 33 33 35	8 8 8 8	SNL 522-619 SNL 524-620 SNL 526	378 378 414	44 44 46	8 8 12
SNL 505	152	16	5	SNL 528	458	54	12
SNL 506-605	172	19	5	SNL 530	486	58	12
SNL 507-606	172	19	5	SNL 532	506	58	12
SNL 508-607 SNL 509 SNL 510-608	188 188 188	22 22 22	6 6 6				

3 Product data

Page 46

the drive-up should be stopped. A particularly simple method of mounting self-aligning ball bearings on adapter sleeves is the use of the spanner set TMHN 7 which has been specially developed for this purpose. Each spanner is marked with the angle though which the lock nut should be turned when self-aligning ball bearings having C3 radial internal clearance are used.

CARB bearings can also be mounted on cylindrical as well as tapered seatings. For tapered seatings, again normally adapter sleeves are employed; the spanner set TMHN 7 can be used for smaller CARB bearings as well as for self-aligning ball bearings. For larger CARB bearings either the clearance reduction or the axial drive-up length should be measured. When using a feeler gauge to measure clearance reduction it is important that the inner and outer rings of the bearing are not displaced with respect to each other. The new SKF drive-up method can also be applied.

Bearings with cylindrical bore are normally mounted with an interference fit on the shaft. Appropriate shaft tolerances should be selected. The recommendations applying to self-aligning ball and spherical roller bearings also apply to CARB bearings.

Details of the spanner set TMHN 7, several other mounting tools as well as the new SKF drive-up method can be found in the SKF catalogue MP200 "Tools for trouble-free operation" which will be sent on request.

Support surface for housing base

To guarantee long bearing service life it is recommended that the support surface for the housing is finished to $R_a \leq 12.5 \mu m$. The flatness (planicity) tolerance should be to IT7. For moderate demands IT8 may be satisfactory.

Dowel pins

SNL housings are designed for loads acting vertically to the housing base support. If they are to be subjected to moderate or heavy loads acting paral-

Position and size of dowel pin holes

Page 3

lel to the base support, a stop should be provided, or the housing should be pinned to its support. Recommendations for the position and size of holes to take dowel pins are given in **Table 4** on **page 31**.

Housings for four-bolt mounting

For the attachment of SNL housings to T-shaped beams, it is possible to drill four bolt holes in the base. The appropriate positions are indicated by dimples. Recommended dimensions are given in **Table 5**.

Some housings which are already prepared for four-bolt mounting can be supplied. These housings are also prepared for relubrication of the bearing via the outer ring (suffix NM) as standard. Available sizes are shown in **Table 6**. The housings are designated FSNL .. NM, e.g. FSNL 511-609 NM.

Attachment bolts

It is recommended that hexagon headed bolts to strength class 8.8 according to ISO 4014:1999 should be used. If the load does not act vertically to the base, it may be necessary to use stronger, class 10.9 bolts. Details of the appropriate tightening torques for the bolts to class 8.8 are given in **Table 2** on **page 48**.

2 Recommendations

3 Product data



Housing	Dimensi	ons	N_2	Appropriate
Size	J ₁	J ₂		bolt size
_	mm			mm
SNL 208-307	160	34	11	M 10
SNL 209	160	34	11	M 10
SNL 210	160	34	11	M 10
SNL 211	200	40	14	M 12
SNL 212	200	40	14	M 12
SNL 213	220	48	14	M 12
SNL 215 SNL 216 SNL 217 SNL 218	220 252 252 280	48 52 52 58	14 18 18 18	M 12 M 16 M 16 M 16 M 16
SNL 508-607	160	34	11	M 10
SNL 509	160	34	11	M 10
SNL 510-608	160	34	11	M 10
SNL 511-609	200	40	14	M 12
SNL 512-610	200	40	14	M 12
SNL 513-611	220	48	14	M 12
SNL 515-612	220	48	14	M 12
SNL 516-613	252	52	18	M 16
SNL 517	252	52	18	M 16
SNL 518-615	280	58	18	M 16
SNL 519-616	280	58	18	M 16
SNL 520-617	300	66	18	M 16
SNL 522-619	320	74	18	M 16
SNL 524-620	330	74	18	M 16
SNL 526	370	80	22	M 20
SNL 528	400	92	26	M 24
SNL 530	430	100	26	M 24
SNL 532	450	100	26	M 24

Page 3

2 Recommendations

Mounting

3 Product data

Page 46



Housing Size	Dimensi N	ons N ₁	J ₁	J ₂	J ₆
-	mm				
FSNL 511-609 NM	20	15	210	35	234
FSNL 513-611 NM	20	15	230	40	252
FSNL 515-612 NM	20	15	230	40	257
FSNL 516-613 NM	24	18	260	50	288
FSNL 517 NM	24	18	260	50	292
FSNL 518-615 NM	24	18	290	50	317
FSNL 520-617 NM	24	18	320	60	348
FSNL 522-619 NM	24	18	350	70	378
FSNL 524-620 NM	24	18	350	70	378
FSNL 526 NM	28	22	380	70	414
FSNL 528 NM	32	26	420	80	458
FSNL 530 NM	32	26	450	90	486
FSNL 532 NM	32	26	470	90	506

Bolt hole dimensions

•

2

Page 3

Mounting SNL housings with double-lip seals

Before starting installation work, the following instructions should be carefully read.

1. Ensure that the environment is clean. Check the dimensional and form accuracy of the shaft seating.

2. Check that the surface roughness of the support surface $R_a \leq 12.5 \mu m$. The flatness (planicity) tolerance should be to IT7. For moderate demands IT8 may be satisfactory.

3. If the bearing is mounted on an adapter sleeve, determine the position of the housing. The grease nipple arranged at one side of the housing cap (for improved lubrication) should be at the side opposite to the sleeve nut. Where housings are mounted at shaft ends, grease should be applied at the end cover side. It is necessary to consider the complete housing as the base and cap will only fit together as supplied.

4. Position the housing on the support surface. Fit the attachment bolts but do not tighten them.

5. Insert one seal half in each of the grooves in the housing base. Fill the space between the two sealing lips with grease. If the housing is to be used at the end of a shaft, insert an end cover at one side instead of the seal half.

6. Mount the bearing on the shaft – either directly on a stepped shaft or using an adapter sleeve. Completely fill the bearing with grease. The remainder of the recommended grease quantity should be put in the housing base at the sides (→ Table 1, page 28).

7. Lay the shaft with bearing in the housing base.

2 Recommendations

Mounting

8. Put one locating ring (when needed) at each side of the bearing.

NB. Locating rings are only used for locating bearing arrangements, except for CARB bearings which, although always non-locating, must always be mounted with locating rings.

9. Carefully align the housing base. Vertical markings at the middle of the side faces and ends of the housing base can facilitate this. Then lightly tighten the attachment bolts.

10. The remaining seal halves should be inserted in the seal grooves in the housing cap and the space between the sealing lips filled with grease.

11. The housing cap should be placed over the base and the cap bolts (to join cap and base) tightened to the torque specified in **Table 2** on **page 48**. The cap and base of one housing are not interchangeable with those of other housings. The cap and base should be checked to see that they bear the same identification.

12. Fully tighten the attachment bolts in the housing base. Recommended tightening torques are given inTable 2 on page 48.

3 Product data



Page 3

Mounting SNL housings with V-ring seals

Before starting installation work, the following instructions should be carefully read.

1. Ensure that the environment is clean. Check the dimensional and form accuracy of the shaft seating.

2. Check that the surface roughness of the support surface $R_a \leq 12.5 \mu m$. The flatness (planicity) tolerance should be to IT7. For moderate demands IT8 may be satisfactory.

3. If the bearing is mounted on an adapter sleeve, determine the position of the housing. The grease nipple arranged at one side of the housing cap (for improved lubrication) should be at the side opposite to the sleeve nut. Where housings are mounted at shaft ends, grease should be applied at the end cover side. It is necessary to consider the complete housing as the base and cap will only fit together as supplied.

4. Position the housing on the support surface. Fit the attachment bolts but do not tighten them.

5. Arrange the one V-ring with sealing washer on the shaft. The V-ring should be furthest away from the bearing and seal against the washer, i.e. the lip should point inwards towards the washer.

6. Mount the bearing on the shaft – either directly on a stepped shaft or using an adapter sleeve. Completely fill the bearing with grease. The remainder of the recommended grease quantity should be put in the housing base at the sides (→ Table 1, page 28).

7. Arrange the second sealing washer and V-ring on the shaft at the other side of the bearing. If the housing is to be used at the end of a shaft, mount an end cover instead.

2 Recommendations

Mounting

8. Lay the shaft with bearing and sealing washers in the housing base.

9. Put one locating ring (when needed) at each side of the bearing.

NB. Locating rings are only used for locating bearing arrangements, except for CARB bearings which, although always non-locating, must always be mounted with locating rings.

10. Carefully align the housing base. Vertical markings at the middle of the side faces and ends of the housing base can facilitate this. Then lightly tighten the attachment bolts.

11. The housing cap should be placed over the base and the cap bolts (to join cap and base) tightened to the torque specified in **Table 2** on **page 48**. The cap and base of one housing are not interchangeable with those of other housings. The cap and base should be checked to see that they bear the same identification.

12. Fully tighten the attachment bolts in the housing base. Recommended tightening torques are given inTable 2 on page 48.

13. Coat the V-ring counterfaces on the sealing washers with grease.

14. Finally, push the V-ring seals into their correct position. This can be done using a screwdriver at the same time as the shaft is turned.

3 Product data


Page 3

Mounting SNL housings with felt seals

Before starting installation work, the following instructions should be carefully read.

1. Ensure that the environment is clean. Check the dimensional and form accuracy of the shaft seating.

2. Check that the surface roughness of the support surface $R_a \leq 12,5 \ \mu\text{m}$. The flatness (planicity) tolerance should be to IT7. For moderate demands IT8 may be satisfactory.

3. If the bearing is mounted on an adapter sleeve, determine the position of the housing. The grease nipple arranged at one side of the housing cap (for improved lubrication) should be at the side opposite to the sleeve nut. Where housings are mounted at shaft ends, grease should be applied at the end cover side. It is necessary to consider the complete housing as the base and cap will only fit together as supplied.

4. Position the housing on the support surface. Fit the attachment bolts but do not tighten them.

5. Insert the rubber O-section cords in the grooves in the housing base. If the housing is to be used at the end of a shaft, insert an end cover at one side instead of one O-section cord.

6. Place one felt ring seal half (in light alloy ring) over the O-section cord in each sealing groove in the housing base. (Details regarding mounting of loose FS felt strips \rightarrow page 18). If the housing is to be used at a shaft end, the second felt ring seal half is omitted and an end cover inserted in the housing base instead.

7. Mount the bearing on the shaft – either directly on a stepped shaft or using an adapter sleeve. Completely fill the bearing with grease. The remainder of the recommended grease quantity should be put in the housing base at the sides (\rightarrow Table 1, page 28).

2 Recommendations

Mounting

3 Product data

Page 46

8. Lay the shaft with bearing in the housing base.

9. Put one locating ring (when needed) at each side of the bearing.

NB. Locating rings are only used for locating bearing arrangements, except for CARB bearings which, although always non-locating, must always be mounted with locating rings.

10. Carefully align the housing base. Vertical markings at the middle of the side faces and ends of the housing base can facilitate this. Then lightly tighten the attachment bolts.

11. Put the O-ring cord into the sealing grooves in the housing cap.

12. The remaining seal halves should be inserted in the seal grooves in the housing cap over the O-ring cords.

13. The housing cap should be placed over the base and the cap bolts (to join cap and base) tightened to the torque specified in **Table 2** on **page 48**. The cap and base of one housing are not interchangeable with those of other housings. The cap and base should be checked to see that they bear the same identification.

14. Fully tighten the attachment bolts in the housing base. Recommended tightening torques are given inTable 2 on page 48.



Page 3

Mounting SNL housings with labyrinth seals

Before starting installation work, the following instructions should be carefully read.

1. Ensure that the environment is clean. Check the dimensional and form accuracy of the shaft seating.

2. Check that the surface roughness of the support surface $R_a \leq 12.5 \mu m$. The flatness (planicity) tolerance should be to IT7. For moderate demands IT8 may be satisfactory.

3. If the bearing is mounted on an adapter sleeve, determine the position of the housing. The grease nipple arranged at one side of the housing cap (for improved lubrication) should be at the side opposite to the sleeve nut. Where housings are mounted at shaft ends, grease should be applied at the end cover side. It is necessary to consider the complete housing as the base and cap will only fit together as supplied.

4. Position the housing on the support surface. Fit the attachment bolts but do not tighten them.

5. Mount the first labyrinth seal on the shaft in the correct position.

6. Mount the bearing on the shaft – either directly on a stepped shaft or using an adapter sleeve. Completely fill the bearing with grease. The remainder of the recommended grease quantity should be put in the housing base at the sides (\rightarrow Table 1, page 28).

7. Mount the second labyrinth ring on the shaft in the correct position. If the housing is to be used at a shaft end, the second labyrinth ring is omitted and an end cover inserted in the housing base instead.

8. Lay the shaft with bearing and laby-rinth ring(s) in the housing base.

2 Recommendations

Mounting

9. Put one locating ring (when needed) at each side of the bearing.

NB. Locating rings are only used for locating bearing arrangements, except for CARB bearings which, although always non-locating, must always be mounted with locating rings.

10. Carefully align the housing base. Vertical markings at the middle of the side faces and ends of the housing base can facilitate this. Then lightly tighten the attachment bolts.

11. The housing cap should be placed over the base and the cap bolts (to join cap and base) tightened to the torque specified in **Table 2** on **page 48**. The cap and base of one housing are not interchangeable with those of other housings. The cap and base should be checked to see that they bear the same identification.

12. Fully tighten the attachment bolts in the housing base. Recommended tightening torques are given inTable 2 on page 48.

13. Finally insert the hollow O-ring cord of synthetic rubber in the grooves in the labyrinth rings. This can be done using a screwdriver while turning the shaft.

3 Product data



Page 3

Mounting SNL housings with taconite seals

Before starting installation work, the following instructions should be carefully read.

1. Ensure that the environment is clean. Check the dimensional and form accuracy of the shaft seating.

2. Check that the surface roughness of the support surface $R_a \leq 12.5 \mu m$. The flatness (planicity) tolerance should be to IT7. For moderate demands IT8 may be satisfactory.

3. If the bearing is mounted on an adapter sleeve, determine the position of the housing. The grease nipple arranged at one side of the housing cap (for improved lubrication) should be at the side opposite to the sleeve nut. Where housings are mounted at shaft ends, grease should be applied at the end cover side. It is necessary to consider the complete housing as the base and cap will only fit together as supplied.

4. Position the housing on the support surface. Fit the attachment bolts but do not tighten them.

5. Mount the first V-ring together with one labyrinth seal on the shaft in the correct position. The lip of the V-ring should point towards the bearing. Place the split ring over the V-ring and labyrinth ring and screw together. The two parts of this split ring are not inter-changeable. They should be checked to see that they carry the same identification.

6. Mount the bearing on the shaft – either directly on a stepped shaft or using an adapter sleeve. Completely fill the bearing with grease. The remainder of the recommended grease quantity should be put in the housing base at the sides (\rightarrow Table 1, page 28).

2 Recommendations

Mounting

7. Mount the second seal according to point 5. If the housing is to be used at a shaft end, the second seal is omitted and an end cover inserted in the housing base instead.

8. Use the hollow O-section cord to fix the labyrinth ring in position on the shaft. A screwdriver can be used to fit the cords whilst rotating the shaft. Mount the O-ring on the seal outer diameter.

9. Lay the shaft with bearing and seals in the housing base taking care that the O-rings are not damaged.

10. Put one locating ring (when needed) at each side of the bearing.

NB. Locating rings are only used for locating bearing arrangements, except for CARB bearings which, although always non-locating, must always be mounted with locating rings.

11. Carefully align the housing base. Vertical markings at the middle of the side faces and ends of the housing base can facilitate this. Then lightly tighten the attachment bolts.

12. The housing cap should be placed over the base and the cap bolts (to join cap and base) tightened to the torque specified in **Table 2** on **page 48**. The cap and base of one housing are not interchangeable with those of other housings. The cap and base should be checked to see that they bear the same identification.

13. Fully tighten the attachment bolts in the housing base. Recommended tightening torques are given inTable 2 on page 48.

14. Finally, before the first test run, rotate the shaft and supply grease via the nipple until it exudes from the labyrinth rings. The same grease as that used for the bearing should also be used to lubricate the labyrinth rings.

3 Product data



Page 3

Mounting SNL housings with oil seals

Before starting installation work, the following instructions should be carefully read.

1. Ensure that the environment is clean. Check the dimensional and form accuracy of the shaft seating.

2. Check that the surface roughness of the support surface $R_a \leq 12.5 \ \mu\text{m}$. The flatness (planicity) tolerance should be to IT7.

3. If the bearing is mounted on an adapter sleeve, determine the position of the housing.

4. Position the housing on the support surface. Fit the attachment bolts but do not tighten them.

5. Assemble the seals. Check if the O-ring and silicon tubes are at their right positions in respective groove $(\rightarrow fig \ \ \ \)$ on page 20).

6. Cover the shaft with a thin layer of oil. Slide the first seal to its right mounting position, some millimetres outside its working position.

7. Mount the bearing on the shaft – either directly on a stepped shaft or using an adapter sleeve.

8. Slide the second seal to the right position on the shaft, as described in point 6. If the housing is to be used at a shaft end, the second seal is omitted and the inner part of the end cover is inserted in the housing base seal groove.

9. Lay the shaft with bearing and seal assemblies in the housing base.

10. Put one locating ring (when needed) at each side of the bearing.

NB. Locating rings are only used for locating bearing arrangements, except for CARB bearings which, although always non-locating, must always be mounted with locating rings.

2 Recommendations

Mounting

11. Carefully align the housing base. Vertical markings at the middle of the side faces and ends of the housing base can facilitate this. Then lightly tighten the attachment bolts.

12. Cover the mating surfaces of the housing with oil-resistant sealant Loctite 573 or equal. The housing cap should be placed over the base and the cap bolts (to join cap and base) tightened to the torque specified in **Table 2** on **page 48**. The cap and base of one housing are not inter-changeable with those of other housings. The cap and base should be checked to see that they bear the same identification.

13. Fully tighten the attachment bolts in the housing base. Recommended tightening torques are given in Table
2 on page 48.

14. Slide the seals against the housing side surfaces. Mount the seal-mounting screws and tighten them. If an end cover has been mounted fully tighten the screw on the external part of the end cover.

15. Mount the supplied ventilating plug on the top of the housing and when oil bath shall be used, mount the oil level sight glass. When circulating oil lubrication shall be used connect the oil inlet and outlet pipes to the housing.

16. When oil bath is used, the max and min oil level should be indicated on the sight glass. Recommended oil level to be used for the mounted bearing can be found in **Table 3** on **page 30**.

NB. For oil bath it is important not to overfill the max level as this can cause oil leakage from the housing. For circulating oil is it important that the outlet pipe/pipes can drain the housing in a proper way to avoid overfill of oil inside the housing.

17. Protect the housing assembly from negative pressure from surrounding equipment.

3 Product data



Designations

The designations used for SNL housings consist of a basic designation which identifies the design, material and size followed by any supplementary designations needed to identify features which differ from the standard design. A dash (-) in the chart indicates that the features belong to the standard design.

Designation chart

Varia	FSNL 522-619 NMSN
– F S	Two holes for attachment bolts Four cast holes for attachment bolts No holes
Basi	c design
_	Housing of grey cast iron
Size	
205 t 505 t	o 218 o 532
Suffi	xes
NM	Drilled and tapped hole 1/8-27 NPSF positioned at the centre of the cap for bearings with annular groove and three lubrication holes in the outer ring. Grease nipple AH 1/8-27 PTF is supplied with the housing
MS2	Four drilled holes for attachment bolts
T	Drilled and tapped hole 1/4-28 UNF at one side of the cap to take grease nipple AH 1/4-28 SAE-LT for relubrication of seal; nipple supplied with housing.

- **TD** Drilled and tapped hole 1/4-28 UNF at both sides of cap to take grease nipple AH 1/4-28 SAE-LT for lubrication of seals, two nipples supplied with housing.
- **SN** Housing with drilled and tapped hole for sensor position 3 (see Fig 1 on page 27)
- K7 Housing with bearing seating diameter tolerance K7

Where two or more suffixes are used they are given in the same order as above.

Page 3

Load carrying ability

SNL plummer block housings are intended for loads acting vertically towards the base plate (support). If loads acting in other directions occur, checks should be made to ensure that the magnitude of the load is permissible for the housing, the bolts joining the housing cap and base, and for the attachment bolts.

Load carrying ability of the housing

Guideline values for the breaking load P of the housing for various load directions are given in **Table** 1. Using these values and a safety factor selected with respect to the operating conditions, the permissible load for the housing can be calculated. In general engineering a safety factor of 6 is often used. For special purposes where extra strength and resistance to shock loads are required, SKF supplies as standard a range of dimensionally equivalent spheroidal graphite cast iron housings. For housings made of spheroidal graphite cast iron the values for P obtained from Table 1 should be multiplied by 1,8.

It is important for the load carrying ability of the housing that the bolts joining cap and base are properly tightened in accordance with the values given in **Table 2** on **page 48**. The axial load carry-ing capacity of the housing is approx-imately 65 % of P_{180° . For load angles between 55 and 120° as well as for axial loads, or if the load acting parallel

to the base plate (support surface) exceeds 5 % of P_{180° , the housing should be pinned to the support or a stop should be provided in the direction of the load.

Breaking loads for SNL plummer block housings

2 Recommendations

Page 10

3 Product data

Load carrying ability





Housing Size	Breaking P _{55°}	loads for S P _{90°}	NL housing P _{120°}	P _{150°}	P _{180°}	Pa
_	kN					
SNL 205	155	95	70	60	80	52
SNL 206-305	170	100	80	65	85	55
SNL 207	190	115	85	80	95	60
SNL 208-307	215	130	95	85	110	70
SNL 209	230	140	100	90	115	75
SNL 210	265	155	120	110	130	85
SNL 211	275	170	125	115	140	90
SNL 212	300	180	130	120	150	100
SNL 213	340	205	150	130	170	110
SNL 215	410	250	185	160	205	135
SNL 216	430	260	190	175	215	140
SNL 217	480	290	205	190	240	155
SNL 218	550	340	250	215	275	180
SNL 505	155	95	70	60	80	52
SNL 506-605	170	100	80	65	85	55
SNL 507-606	190	115	85	80	95	60
SNL 508-607	215	130	95	85	110	70
SNL 509	230	140	100	90	115	75
SNL 510-608	265	155	120	110	130	85
SNL 511-609	275	170	125	115	140	90
SNL 512-610	300	180	130	120	150	100
SNL 513-611	340	205	150	130	170	110
SNL 515-612	410	250	185	160	205	135
SNL 516-613	430	260	190	175	215	140
SNL 517	480	290	205	190	240	155
SNL 518-615	550	340	250	215	275	180
SNL 519-616	580	350	260	230	290	190
SNL 520-617	620	370	280	250	310	200
SNL 522-619	680	410	310	275	340	220
SNL 524-620	790	470	350	320	400	260
SNL 526	900	540	410	360	450	295
SNL 528	1 050	630	470	430	530	345
SNL 530	1 200	730	540	480	600	390
SNL 532	1 450	860	640	570	720	470



1 Product info	rmation		2	Recom	mendatio	ons		3 Product da	ita	
Page 3	ł		P	'age	10			Load carryin	g ability	
										Table 2
]	[]			
		Q _{120°} F _{120°}			Q ₁ F ₁	50° 50°		Q _{180°} F _{180°}		
Housing Size	Cap bo Yield po for both Q _{120°}	olts oint n bolts Q _{150°}	Q _{180°}	Maxim for botl F _{120°}	um load n bolts F _{150°}	F _{180°}	Tightening torque	Designation	Attachn Size	n ent bolts Tightening torque
_	kN			kN			Nm		_	Nm
SNL 205	150	85	75	50	30	25	50	M 10×40	M 12	90
SNL 206-305	150	85	75	50	30	25	50	M 10×40	M 12	90
SNL 207	150	85	75	50	30	25	50	M 10×50	M 12	90
SNL 208-307	150	85	75	50	30	25	50	M 10×50	M 12	90
SNL 209	150	85	75	50	30	25	50	M 10×50	M 12	90
SNL 210	150	85	75	50	30	25	50	M 10×55	M 12	90
SNL 211	220	125	110	80	45	40	80	M 12×60	M 16	220
SNL 212	220	125	110	80	45	40	80	M 12×60	M 16	220
SNL 213	220	125	110	80	45	40	80	M 12×65	M 16	220
SNL 215	220	125	110	80	45	40	80	M 12×65	M 16	220
SNL 216	220	125	110	80	45	40	80	M 12×70	M 20	430
SNL 217	220	125	110	80	45	40	80	M 12×80	M 20	430
SNL 218	400	230	200	170	100	85	150	M 16×90	M 20	430
SNL 505	150	85	75	50	30	25	50	M 10×40	M 12	90
SNL 506-605	150	85	75	50	30	25	50	M 10×40	M 12	90
SNL 507-606	150	85	75	50	30	25	50	M 10×50	M 12	90
SNL 508-607	150	85	75	50	30	25	50	M 10×50	M 12	90
SNL 509	150	85	75	50	30	25	50	M 10×50	M 12	90
SNL 510-608	150	85	75	50	30	25	50	M 10×55	M 12	90
SNL 511-609	220	125	110	80	45	40	80	M 12×60	M 16	220
SNL 512-610	220	125	110	80	45	40	80	M 12×60	M 16	220
SNL 513-611	220	125	110	80	45	40	80	M 12×65	M 16	220
SNL 515-612	220	125	110	80	45	40	80	M 12×65	M 16	220
SNL 516-613	220	125	110	80	45	40	80	M 12×70	M 20	430
SNL 517	220	125	110	80	45	40	80	M 12×80	M 20	430
SNL 518-615	400	230	200	170	100	85	150	M 16×90	M 20	430
SNL 519-616	400	230	200	170	100	85	150	M 16×90	M 20	430
SNL 520-617	620	360	310	260	150	130	200	M 20×100	M 24	750
SNL 522-619	620	360	310	260	150	130	200	M 20×100	M 24	750
SNL 524-620	620	360	310	260	150	130	200	M 20×110	M 24	750
SNL 526	900	500	450	380	220	190	350	M 24×130	M 24	750
SNL 528	900	500	450	380	220	190	350	M 24×130	M 30	1 400
SNL 530	900	500	450	380	220	190	350	M 24×130	M 30	1 400
SNL 532	900	500	450	380	220	190	350	M 24×130	M 30	1 400

Page 3

2 Recommendations

Page 10

3 Product data

Load carrying ability

Load carrying ability of bolts

SNL plummer block housings are supplied with cap bolts (to join cap and base) to strength class 8.8 as standard. The guideline values for the yield point Q for the cap bolts are given in **Table 2** for various load directions as well as the corresponding maximum radial loads F.

3

Load carrying ability and tightening torques for cap bolts and attachment bolts

1 Pr	odu	ct i	nfor	nati	ion				2	Rec	ommend	lations	3 Prod	uct data	
Page)		3	-C _a -					Pa	age		10	SNL pl for bea d _a 20 -	ummer block h rings on adapt - 35 mm	ousings er sleeves
D _a d	a +						1 +	H							0
		Do G c	uble-l desigi	ip se ר	eals					l	_abyrinth s S design	eals	Taconite seals ND design	X	-
naft	Hor Din A	usin nen: A ₁	ig sions H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Designations Housing complete with two seals	Components Housing only	Seals	End cover
m	mm	۱									kg	-			
)	67	46	74	40	19	130	165	20	15	12	1,45	SNL 505 TG SNL 505 TA SNL 505 TC SNL 505 TS SNL 505 TND	SNL 505 SNL 505 SNL 505 SNL 505 SNL 505 SNL 505	TSN 505 G TSN 505 A TSN 505 C TSN 505 S TSN 505 ND	ASNH 505 ASNH 505 ASNH 505 ASNH 505 ASNH 505
	77	52	89	50	22	150	185	20	15	12	2,00	SNL 605 TG SNL 605 TA SNL 605 TC SNL 605 TS SNL 605 TND	SNL 506-605 SNL 506-605 SNL 506-605 SNL 506-605 SNL 506-605	TSN 605 G TSN 605 A TSN 605 C TSN 605 S TSN 605 ND	ASNH 506-605 ASNH 506-605 ASNH 506-605 ASNH 506-605 ASNH 506-605
5	77	52	89	50	22	150	185	20	15	12	2,00	SNL 506 TG SNL 506 TA SNL 506 TC SNL 506 TS SNL 506 TND	SNL 506-605 SNL 506-605 SNL 506-605 SNL 506-605 SNL 506-605 SNL 506-605	TSN 506 G TSN 506 A TSN 506 C TSN 506 S TSN 506 ND	ASNH 506-605 ASNH 506-605 ASNH 506-605 ASNH 506-605 ASNH 506-605
	82	52	93	50	22	150	185	20	15	12	2,20	SNL 606 TG SNL 606 TA SNL 606 TC SNL 606 TS SNL 606 TND	SNL 507-606 SNL 507-606 SNL 507-606 SNL 507-606 SNL 507-606	TSN 606 G TSN 606 A TSN 606 C TSN 606 S TSN 606 ND	ASNH 507-606 ASNH 507-606 ASNH 507-606 ASNH 507-606 ASNH 507-606
0	82	52	93	50	22	150	185	20	15	12	2,20	SNL 507 TG SNL 507 TA SNL 507 TC SNL 507 TS SNL 507 TND	SNL 507-606 SNL 507-606 SNL 507-606 SNL 507-606 SNL 507-606	TSN 507 G TSN 507 A TSN 507 C TSN 507 S TSN 507 ND	ASNH 507-606 ASNH 507-606 ASNH 507-606 ASNH 507-606 ASNH 507-606
	85	60	107	60	25	170	205	20	15	12	2,90	SNL 607 TG SNL 607 TA SNL 607 TC SNL 607 TS SNL 607 TND	SNL 508-607 SNL 508-607 SNL 508-607 SNL 508-607 SNL 508-607	TSN 607 G TSN 607 A TSN 607 C TSN 607 S TSN 607 ND	ASNH 508-607 ASNH 508-607 ASNH 508-607 ASNH 508-607 ASNH 508-607
5	85	60	108	60	25	170	205	20	15	12	2,90	SNL 508 TG SNL 508 TA SNL 508 TC SNL 508 TS SNL 508 TND	SNL 508-607 SNL 508-607 SNL 508-607 SNL 508-607 SNL 508-607	TSN 508 G TSN 508 A TSN 508 C TSN 508 S TSN 508 ND	ASNH 508-607 ASNH 508-607 ASNH 508-607 ASNH 508-607 ASNH 508-607
	90	60	113	60	25	170	205	20	15	12	3,20	SNL 608 TG SNL 608 TA SNL 608 TC SNL 608 TS SNL 608 TND	SNL 510-608 SNL 510-608 SNL 510-608 SNL 510-608 SNL 510-608	TSN 608 G TSN 608 A TSN 608 C TSN 608 S TSN 608 ND	ASNH 510-608 ASNH 510-608 ASNH 510-608 ASNH 510-608 ASNH 510-608

2 Recommendations

Page 10





Shaft	Bear seat	ring ing	Widt acro	th ss	Appropriate bearings a Self-aligning ball bearing	nd associa Adapter	ted components Locating rings	Self-aligning ball bearing	Adapter	Locating
d _a	C_{a}	Da	A ₂	A ₃	Spherical folier bearing	SIEEVE	z per nousing	CARB bearing	SIEEVE	2 per housing
mm	mm		mm		-					
20	25	52	80	125	1205 EK –	H 205 -	FRB 5/52 -	2205 EK 22205 CCK/W33 C 2205 K	H 305 H 305 H 305 E	FRB 3.5/52 FRB 3.5/52 FRB 3.5/52
	32	62	89	135	1305 EK _	H 305 -	FRB 7.5/62	2305 EK - -	H 2305 -	FRB 4/62 -
25	32	62	89	135	1206 EK	H 206 _	FRB 8/62 -	2206 EK 22206 CCK/W33 C 2206 K	H 306 H 306 H 306 E	FRB 6/62 FRB 6/62 FRB 6/62
	34	72	94	140	1306 EK	H 306 -	FRB 7.5/72 -	2306 K _ _	H 2306 _ _	FRB 3.5/72 _ _
30	34	72	94	145	1207 EK	H 207 _	FRB 8.5/72 -	2207 EK 22207 CCK/W33 C 2207 K	H 307 H 307 H 307 E	FRB 5.5/72 FRB 5.5/72 FRB 5.5/72
	39	80	97	145	1307 EK _	H 307 -	FRB 9/80 	2307 EK _ _	H 2307 _ _	FRB 4/80 -
35	39	80	97	150	1208 EK -	H 208 -	FRB 10.5/80 -	2208 EK 22208 EK C 2208 K	H 308 H 308 H 308 E	FRB 8/80 FRB 8/80 FRB 8/80
	41	90	102	150	1308 EK 21308 CCK	H 308 H 308	FRB 9/90 FRB 9/90	2308 EK 22308 CCK/W33	H 2308 H 2308	FRB 4/90 FRB 4/90

1 Pr	oduc	t inf	form	atio	n			2	Re	com	mendati	ons	3 Produ	ct data	
Page)		. 3 —Ca-					F	age		10		SNL plu for beari da 40 – 5	mmer block l ings on adap 50 mm	nousings ter sleeves
D _a d _a			— A —				H H			yrinth	A ₂ — seals			Oil se	
	G design								S de	esign		ND c	lesign	U des	lign
Shaft d _a	Hou Dim A	sing ensi A ₁	ons H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Designations Housing complete with two seals	Components Housing only	Seals	End cover
mm	mm										kg	-			
40	85	60	109	60	25	170	205	20	15	12	2,90	SNL 509 TG SNL 509 TA SNL 509 TC SNL 509 TS SNL 509 TND	SNL 509 SNL 509 SNL 509 SNL 509 SNL 509 SNL 509	TSN 509 G TSN 509 A TSN 509 C TSN 509 S TSN 509 ND	ASNH 509 ASNH 509 ASNH 509 ASNH 509 ASNH 509 ASNH 509
	95	70	127	70	28	210	255	24	18	16	4,40	SNL 609 TG SNL 609 TA SNL 609 TC SNL 609 TS SNL 609 TND SNL 609 TURU	SNL 511-609 SNL 511-609 SNL 511-609 SNL 511-609 SNL 511-609 SNL 511-609 RU	TSN 609 G TSN 609 A TSN 609 C TSN 609 S TSN 609 ND TSN 609 U	ASNH 511-609 ASNH 511-609 ASNH 511-609 ASNH 511-609 ASNH 511-609 ASNH 511-609 R
45	90	60	113	60	25	170	205	20	15	12	3,20	SNL 510 TG SNL 510 TA SNL 510 TC SNL 510 TS SNL 510 TND	SNL 510-608 SNL 510-608 SNL 510-608 SNL 510-608 SNL 510-608 SNL 510-608	TSN 510 G TSN 510 A TSN 510 C TSN 510 S TSN 510 ND	ASNH 510-608 ASNH 510-608 ASNH 510-608 ASNH 510-608 ASNH 510-608 ASNH 510-608
	105	70	133	70	30	210	255	24	18	16	5,10	SNL 610 TG SNL 610 TA SNL 610 TC SNL 610 TS SNL 610 TND SNL 610 TURU	SNL 512-610 SNL 512-610 SNL 512-610 SNL 512-610 SNL 512-610 SNL 512-610 RU	TSN 610 G TSN 610 A TSN 610 C TSN 610 S TSN 610 ND TSN 610 U	ASNH 512-610 ASNH 512-610 ASNH 512-610 ASNH 512-610 ASNH 512-610 ASNH 512-610 R
50	95	70	128	70	28	210	255	24	18	16	4,40	SNL 511 TG SNL 511 TA SNL 511 TC SNL 511 TS SNL 511 TND SNL 511 TURU	SNL 511-609 SNL 511-609 SNL 511-609 SNL 511-609 SNL 511-609 SNL 511-609 SNL 211 RU	TSN 511 G TSN 511 A TSN 511 C TSN 511 S TSN 511 ND TSN 511 U	ASNH 511-609 ASNH 511-609 ASNH 511-609 ASNH 511-609 ASNH 511-609 ASNH 513-611 R
	110	80	148	80	30	230	275	24	18	16	6,50	SNL 611 TG SNL 611 TA SNL 611 TC SNL 611 TS SNL 611 TND SNL 611 TURU	SNL 513-611 SNL 513-611 SNL 513-611 SNL 513-611 SNL 513-611 SNL 513-611 RU	TSN 611 G TSN 611 A TSN 611 C TSN 611 S TSN 611 ND TSN 611 U	ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 513-611 R

2 Recommendations

Page 10





Shaft d _a	haft Bearing seating a C _a D _a		Widt acro seal A ₂	h ss A ₃	A ₄	Appropriate bearings a Self-aligning ball bearing Spherical roller bearing	and assoc Adapter sleeve	iated componen Locating rings 2 per housing	ts Self-aligning ball bearing Spherical roller bearing CARB bearing	Adapter sleeve	Locating rings 2 per housing
mm	mm		mm			_					
40	30	85	97	150	-	1209 EK _	H 209 _	FRB 5.5/85 -	2209 EK 22209 CCK/W33 C 2209 K	H 309 H 309 H 309 E	FRB 3.5/85 FRB 3.5/85 FRB 3.5/85
	44	100	107	155	112	1309 EK 21309 EK	H 309 H 309	FRB 9.5/100 FRB 9.5/100	2309 EK 22309 CCK/W33 -	H 2309 H 2309 -	FRB 4/100 FRB 4/100 -
45	41	90	102	155	-	1210 EK	H 210 -	FRB 10.5/90 -	2210 EK 22210 CCK/W33 C 2210 K	H 310 H 310 H 310 E	FRB 9/90 FRB 9/90 FRB 9/90
	48	110	117	165	124	1310 EK 21310 EK	H 310 H 310	FRB 10.5/110 FRB 10.5/110	2310 K 22310 CCK/W33 –	H 2310 H 2310 -	FRB 4/110 FRB 4/110 -
50	44	100	107	165	112	1211 EK	H 211 -	FRB 11.5/100 -	2211 EK 22211 EK C 2211 K	H 311 H 311 H 311 E	FRB 9.5/100 FRB 9.5/100 FRB 9.5/100
	51	120	122	170	128	1311 EK 21311 EK	H 311 H 311	FRB 11/120 FRB 11/120	2311 K 22311 EK -	H 2311 H 2311 -	FRB 4/120 FRB 4/120 -

1 P	Product information							2	Re	com	mendat	tions	3 Produ	ct data	
Pag	e	·····	. 3 ⊷Ca					F	age		10		SNL plur for beari da 55 – 6	nmer block l ngs on adap 65 mm	nousings ter sleeves
	Double-lip seals														
	Double-lip seals G design								Lab S de	yrinth esign	seals	Tacı ND	onite seals design	Oil se U des	als ign
Shaft d _a	Hous Dime A	sing ensio A ₁	ons H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Designations Housing complete with two seals	Components Housing only	Seals	End cover
mm	mm										kg	-			
55	105	70	134	70	30	210	255	24	18	16	5,10	SNL 512 TG SNL 512 TA SNL 512 TC SNL 512 TS SNL 512 TND SNL 512 TURU	SNL 512-610 SNL 512-610 SNL 512-610 SNL 512-610 SNL 512-610 SNL 512-610 SNL 212 RU	TSN 512 G TSN 512 A TSN 512 C TSN 512 S TSN 512 ND TSN 512 U	ASNH 512-610 ASNH 512-610 ASNH 512-610 ASNH 512-610 ASNH 512-610 ASNH 512-612 R
	115	80	154	80	30	230	280	24	18	16	7,00	SNL 612 TG SNL 612 TA SNL 612 TC SNL 612 TC SNL 612 TS SNL 612 TND SNL 612 TURU	SNL 515-612 SNL 515-612 SNL 515-612 SNL 515-612 SNL 515-612 SNL 515-612 SNL 515-612 RU	TSN 612 G TSN 612 A TSN 612 C TSN 612 S TSN 612 ND TSN 612 U	ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 515-612 R
60	110	80	149	80	30	230	275	24	18	16	6,50	SNL 513 TG SNL 513 TA SNL 513 TC SNL 513 TC SNL 513 TS SNL 513 TND SNL 513 TURU	SNL 513-611 SNL 513-611 SNL 513-611 SNL 513-611 SNL 513-611 SNL 513-611 SNL 213 RU	TSN 513 G TSN 513 A TSN 513 C TSN 513 C TSN 513 S TSN 513 ND TSN 513 U	ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 516-613 R
	120	90	175	95	32	260	315	28	22	20	9,50	SNL 613 TG SNL 613 TA SNL 613 TC SNL 613 TS SNL 613 TND SNL 613 TURU	SNL 516-613 SNL 516-613 SNL 516-613 SNL 516-613 SNL 516-613 SNL 516-613 SNL 516-613 RU	TSN 613 G TSN 613 A TSN 613 C TSN 613 C TSN 613 S TSN 613 ND TSN 613 U	ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 516-613 R
65	115	80	155	80	30	230	280	24	18	16	7,00	SNL 515 TG SNL 515 TA SNL 515 TC SNL 515 TS SNL 515 TND SNL 515 TURU	SNL 515-612 SNL 515-612 SNL 515-612 SNL 515-612 SNL 515-612 SNL 515-612 SNL 215 RU	TSN 515 G TSN 515 A TSN 515 C TSN 515 S TSN 515 ND TSN 515 U	ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 518-615 R
5	140	100	193	100) 35	290	345	28	22	20	12,5	SNL 615 TG SNL 615 TA SNL 615 TC SNL 615 TS SNL 615 TND SNL 615 TURU	SNL 518-615 SNL 518-615 SNL 518-615 SNL 518-615 SNL 518-615 SNL 518-615 RU	TSN 615 G TSN 615 A TSN 615 C TSN 615 S TSN 615 ND TSN 615 U	ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 518-615 R

2 Recommendations

Page 10

1 Product information





Shaft d _a	Bea seat C _a	ring ting D _a	Widtl acros seal A ₂	h ss A ₃	A ₄	Appropriate bearings a Self-aligning ball bearing Spherical roller bearing	nd assoc Adapter sleeve	iated compone Locating rings 2 per housing	nts Self-aligning ball bearing Spherical roller bearing CARB bearing	Adapter sleeve	Locating rings 2 per housing
mm	mm		mm			-					
55	48	110	117	175	124	1212 EK -	H 212 -	FRB 13/110 -	2212 EK 22212 EK C 2212 K	H 312 H 312 H 312 E	FRB 10/110 FRB 10/110 FRB 10/110
	56	130	127	175	134	1312 EK 21312 EK	H 312 H 312	FRB 12.5/130 FRB 12.5/130	2312 K 22312 EK –	H 2312 H 2312 -	FRB 5/130 FRB 5/130 -
60	51	120	122	180	128	1213 EK -	H 213 -	FRB 14/120 –	2213 EK 22213 CCK/W33 C 2213 K	H 313 H 313 H 313 E	FRB 10/120 FRB 10/120 FRB 10/120
	58	140	138	180	141	1313 EK 21313 EK	H 313 H 313	FRB 12.5/140 FRB 12.5/140	2313 K 22313 EK –	H 2313 H 2313 -	FRB 5/140 FRB 5/140 –
65	56	130	127	175	134	1215 K _	H 215 -	FRB 15.5/130 -	2215 EK 22215 EK C 2215 K	H 315 H 315 H 315 E	FRB 12.5/130 FRB 12.5/130 FRB 12.5/130
	65	160	158	200	159	1315 K 21315 EK	H 315 H 315	FRB 14/160 FRB 14/160	2315 K 22315 EK C 2315 K	H 2315 H 2315 H 2315	FRB 5/160 FRB 5/160 FRB 5/160

1 Pr	Product information								Rec	omr	nendati	ions	3 Produc	ct data	
Page	e		3 	-				Ρ	age		10		SNL plur for beari d _a 70 – 8	nmer block l ngs on adap 85 mm	nousings ter sleeves
D _a d _a							H	ľ							
ļ <u>ļ</u>	Double-lip seals							Ļ		Æ	A ₂				
	Do G	ouble- desig	lip sea n	als					Laby S de	rinth sign	seals	Tac ND	onite seals design	Oil se U des	eals sign
Shaft d _a	Hou Dim A	sing ensio A ₁	ons H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Designations Housing complete with two seals	Components Housing only	Seals	End cover
mm	mm										kg	-			
70	120	90	177	95	32	260	315	28	22	20	9,50	SNL 516 TG SNL 516 TA SNL 516 TC SNL 516 TS SNL 516 TND SNL 516 TURU	SNL 516-613 SNL 516-613 SNL 516-613 SNL 516-613 SNL 516-613 SNL 216 RU	TSN 516 G TSN 516 A TSN 516 C TSN 516 S TSN 516 ND TSN 516 U	ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 216 R
	145	100	210	112	35	290	345	28	22	20	13,7	SNL 616 TG SNL 616 TA SNL 616 TC SNL 616 TS SNL 616 TND SNL 616 TURU	SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 RU	TSN 616 G TSN 616 A TSN 616 C TSN 616 S TSN 616 ND TSN 616 U	ASNH 519-616 ASNH 519-616 ASNH 519-616 ASNH 519-616 ASNH 519-616 ASNH 519-616 R
75	125	90	183	95	32	260	320	28	22	20	10,0	SNL 517 TG SNL 517 TA SNL 517 TC SNL 517 TC SNL 517 TS SNL 517 TND SNL 517 TURU	SNL 517 SNL 517 SNL 517 SNL 517 SNL 517 SNL 517 SNL 217 RU	TSN 517 G TSN 517 A TSN 517 C TSN 517 S TSN 517 ND TSN 517 U	ASNH 517 ASNH 517 ASNH 517 ASNH 517 ASNH 517 ASNH 517 ASNH 217 R
	160	110	218	112	40	320	380	32	26	24	17,6	SNL 617 TG SNL 617 TA SNL 617 TC SNL 617 TC SNL 617 TS SNL 617 TND SNL 617 TURU	SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 RU	TSN 617 G TSN 617 A TSN 617 C TSN 617 S TSN 617 ND TSN 617 U	ASNH 520-617 ASNH 520-617 ASNH 520-617 ASNH 520-617 ASNH 520-617 ASNH 520-617 R
80	140	100	194	100	35	290	345	28	22	20	12,5	SNL 518 TG SNL 518 TA SNL 518 TC SNL 518 TC SNL 518 TS SNL 518 TND SNL 518 TURU	SNL 518-615 SNL 518-615 SNL 518-615 SNL 518-615 SNL 518-615 SNL 518-615 SNL 218 RU	TSN 518 G TSN 518 A TSN 518 C TSN 518 S TSN 518 ND TSN 518 U	ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 218 R
85	145	100	212	112	35	290	345	28	22	20	13,7	SNL 519 TG SNL 519 TA SNL 519 TC SNL 519 TC SNL 519 TS SNL 519 TND SNL 519 TURU	SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 RU	TSN 519 G TSN 519 A TSN 519 C TSN 519 S TSN 519 ND TSN 519 U	ASNH 519-616 ASNH 519-616 ASNH 519-616 ASNH 519-616 ASNH 519-616 ASNH 519-616 R
	175	120	239	125	45	350	410	32	26	24	22,0	SNL 619 TG SNL 619 TA SNL 619 TC SNL 619 TS SNL 619 TND SNL 619 TURU	SNL 522-619 SNL 522-619 SNL 522-619 SNL 522-619 SNL 522-619 SNL 522-619 SNL 522-619 RU	TSN 619 G TSN 619 A TSN 619 C TSN 619 S TSN 619 ND TSN 619 U	ASNH 522-619 ASNH 522-619 ASNH 522-619 ASNH 522-619 ASNH 522-619 ASNH 522-619 R

2 Recommendations

Page 10

Page 3

1 Product information





Shaft d _a	Bear	ring ina	Widt	h ss		Appropriate bearings a Self-aligning ball bearing	Ind asso	ciated compone	ents Self-aligning ball bearing	Adapter	Locating
d _a	C _a	D _a	seal A ₂	A ₃	A ₄	Spherical roller bearing	sleeve	2 per housing	Spherical roller bearing CARB bearing	sleeve	rings 2 per housing
mm	mm		mm		_						
70	58	140	138	205	166	1216 K -	H 216 -	FRB 16/140 -	2216 EK 22216 EK C 2216 K	H 316 H 316 H 316 E	FRB 12.5/140 FRB 12.5/140 FRB 12.5/140
	68	170	163	205	143	1316 K 21316 EK	H 316 H 316	FRB 14.5/170 FRB 14.5/170	2316 K 22316 EK C 2316 K	H 2316 H 2316 H 2316 H 2316	FRB 5/170 FRB 5/170 FRB 5/170
75	61	150	143	210	143	1217 K	H 217 -	FRB 16.5/150 -	2217 К 22217 ЕК С 2217 К	H 317 H 317 H 317 E	FRB 12.5/150 FRB 12.5/150 FRB 12.5/150
	70	180	178	220	181	1317 K 21317 EK	H 317 H 317	FRB 14.5/180 FRB 14.5/180	2317 K 22317 EK C 2317 K	H 2317 H 2317 H 2317	FRB 5/180 FRB 5/180 FRB 5/180
80	65	160	158	225	159	1218 K 22218 EK	H 218 H 318	FRB 17.5/160 FRB 12.5/160	2218 K 23218 CCK/W33 C 2218 K	H 318 H 2318 H 318 E	FRB 12.5/160 FRB 6.25/160 FRB 12.5/160
85	68	170	163	220	166	1219 K _	H 219 -	FRB 18/170 _	2219 K 22219 EK –	H 319 H 319 -	FRB 12.5/170 FRB 12.5/170 -
	80	200	191	235	195	1319 K 21319 EK	H 319 H 319	FRB 17.5/200 FRB 17.5/200	2319 K 22319 EK	H 2319 H 2319	FRB 6.5/200 FRB 6.5/200

1 Pr	oduc	t inf	orm	atior	۱				2	Reco	ommenda	ations		3 Produ	ict data	
Page)	·····	3 C _a -						Pa	ge	1	0		SNL plu for bear da 90 –	mmer bloc ings on ada 135 mm	k housings apter sleeves
D _a d _a																
<u>, </u>			—A –		P					-J_ 	A ₂		-			
	Do G	uble- desig	lip se n	als					L	abyri desi	nth seals ign		Tac ND	onite seals design	Oil U c	seals design
Shaft d _a	Hou Dim A	ising ensi A ₁	ons H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Designations Housing complete with	5	Components Housing	Seals	End cover
mm	mm										kg	-				
90	160	110	218	112	40	320	380	32	26	24	17,6	SNL 520 TG SNL 520 TA SNL 520 TC SNL 520 TS SNL 520 TNE SNL 520 TNE		SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 RU	TSN 520 G TSN 520 A TSN 520 C TSN 520 S TSN 520 ND TSN 520 U	ASNH 520-617 ASNH 520-617 ASNH 520-617 ASNH 520-617 ASNH 520-617 ASNH 520-617 R
	185	120	271	140	45	350	410	32	26	24	26,2	SNL 620 TG SNL 620 TA SNL 620 TC SNL 620 TS SNL 620 TNE SNL 620 TUF		SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 RU	TSN 620 G TSN 620 A TSN 620 C TSN 620 S TSN 620 ND TSN 620 U	ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620 R
100	175	120	242	125	45	350	410	32	26	24	22,0	SNL 522 TG SNL 522 TA SNL 522 TC SNL 522 TS SNL 522 TNE SNL 522 TUR) {U	SNL 522-619 SNL 522-619 SNL 522-619 SNL 522-619 SNL 522-619 SNL 522-619 RU	TSN 522 G TSN 522 A TSN 522 C TSN 522 C TSN 522 S TSN 522 ND TSN 522 U	ASNH 522-619 ASNH 522-619 ASNH 522-619 ASNH 522-619 ASNH 522-619 ASNH 522-619 ASNH 522-619 R
110	185	120	271	140	45	350	410	32	26	24	26,2	SNL 524 TG SNL 524 TA SNL 524 TC SNL 524 TS SNL 524 TNE SNL 524 TUF) {U	SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 RU	TSN 524 G TSN 524 A TSN 524 C TSN 524 S TSN 524 ND TSN 524 U	ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620 R
115	190	130	290	150	50	380	445	35	28	24	33,0	SNL 526 TG SNL 526 TA SNL 526 TC SNL 526 TS SNL 526 TNE SNL 526 TNE SNL 526 TUF) 2U	SNL 526 SNL 526 SNL 526 SNL 526 SNL 526 SNL 526 SNL 526 RU	TSN 526 G TSN 526 A TSN 526 C TSN 526 S TSN 526 ND TSN 526 U	ASNH 526 ASNH 526 ASNH 526 ASNH 526 ASNH 526 ASNH 526 ASNH 526 R
125	205	150	302	150	50	420	500	42	35	30	40,0	SNL 528 TG SNL 528 TA SNL 528 TC SNL 528 TS SNL 528 TNE SNL 528 TUF) 2U	SNL 528 SNL 528 SNL 528 SNL 528 SNL 528 SNL 528 SNL 528 RU	TSN 528 G TSN 528 A TSN 528 C TSN 528 S TSN 528 ND TSN 528 U	ASNH 528 ASNH 528 ASNH 528 ASNH 528 ASNH 528 ASNH 528 ASNH 528 R
135	220	160	323	160	60	450	530	42	35	30	49,0	SNL 530 TG SNL 530 TA SNL 530 TC SNL 530 TS SNL 530 TNE SNL 530 TNE) {U	SNL 530 SNL 530 SNL 530 SNL 530 SNL 530 SNL 530 SNL 530 RU	TSN 530 G TSN 530 A TSN 530 C TSN 530 S TSN 530 ND TSN 530 U	ASNH 530 ASNH 530 ASNH 530 ASNH 530 ASNH 530 ASNH 530 R

2 Recommendations

Page 10





Shaft d _a	Bear seat C _a	r ing ing D _a	Widt acro seal A ₂	h ss A ₃	A ₄	Appropriate bearings a Self-aligning ball bearing Spherical roller bearing	nd assoc Adapter sleeve	ciated compon Locating rings 2 per housing	ents Self-aligning ball bearin Spherical roller bearing CARB bearing	g Adapter sleeve	Locating rings 2 per housing
mm	mm		mm			-					
90	70	180	178	230	181	1220 K 22220 EK	H 220 H 320	FRB 18/180 FRB 12/180	2220 K 23220 CCK/W33 C 2220 K	H 320 H 2320 H 320 E	FRB 12/180 FRB 4.85/180 FRB 12/180
	86	215	199	240	203	1320 K 21320 EK	H 320 H 320	FRB 19.5/215 FRB 19.5/215	2320 K 22320 EK C 2320 K	H 2320 H 2320 H 2320 H 2320	FRB 6.5/215 FRB 6.5/215 FRB 6.5/215
100	80	200	191	250	195	1222 K 22222 EK	H 222 H 322	FRB 21/200 FRB 13.5/200	2222 K 23222 CCK/W33 C 2222 K	H 322 H 2322 H 322 E	FRB 13.5/200 FRB 5.1/200 FRB 13.5/200
110	86	215	199	260	203	1224 K 22224 EK	H 3024 H 3124	FRB 22/215 FRB 14/215	– 23224 CCK/W33 C 3224 K	– H 2324 H 2324 L	– FRB 5/215 FRB 5/215
115	90	230	208	265	211	 22226 EK	– H 3126	_ FRB 13/230	– 23226 CCK/W33 C 2226 K	– H 2326 H 3126 L	– FRB 5/230 FRB 13/230
125	98	250	223	285	225	_ 22228 CCK/W33	– H 3128	_ FRB 15/250	– 23228 CCK/W33 C 2228 K	– H 2328 H 3128 L	– FRB 5/250 FRB 15/250
135	106	270	241	295	241	_ 22230 CCK/W33	– H 3130	– FRB 16.5/270	– 23230 CCK/W33 C 2230 K	– H 2330 H 3130 I	– FRB 5/270 FRB 16.5/270

1 Pr Page	oduc 	t inf	orm 3 Ca Ca Ca		n		- H		21 Pa	ge	ommenda			3 P SNI for da	roduc L plur bearin 140 m	t data nmer blo ngs on ac im	ck housings dapter sleeves
	Do G d	uble- desig	— A – -lip se In	eals	<u>}</u>		<u> </u>			abyrir desię	— A ₂ — nth seals gn		 Ta Ni	A ₃	<u> </u>	- C U	A ₄
Shaft d _a	Hou Dim A	sing ensi A ₁	ons H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Desig Housir comple two se	nations ng ete with eals	Components Housing only		Seals	End cover
mm	mm										kg	-					
	200											SNL 5 SNL 5 SNL 5 SNL 5 SNL 5	32 TA 32 TC 32 TS 32 TND 32 TURU	SNL 532 SNL 532 SNL 532 SNL 532 SNL 532 RU	-	TSN 532 A TSN 532 C TSN 532 S TSN 532 N TSN 532 U	ASNH 532 ASNH 532 ASNH 532 D ASNH 532 ASNH 532 ASNH 532 R

2 Recommendations

Page 10

Page 3

1 Product information





Shaft	Bea seat	ring ing	Widt acro seal	h ss		Appropriate bearings Spherical roller bearing	and asso Adapter sleeve	ociated compor Locating rings 2 per housing	nents Spherical roller bearing CARB bearing) Adapter	Locating rings
d _a	Ca	D _a	A ₂	А ₃	A ₄			1 0			2 per housing
mm	mm		mm			-					
140	114	290	254	315	257	22232 CCK/W33	H 3132	FRB 17/290	23232 CCK/W33 C 3232 K	H 2332 H 2332 L	FRB 5/290 FRB 5/290

1 P	rodu	ct in	form	atio	n				2 Re	comr	mendation	S	3 Produ	ct data	
Pag	e		3	-C _a -	•			F	Page		10		SNL plu for bear d _a 25 –	mmer block I ings with cyli 40 mm	nousings indrical bore
Da	Da db da							H H							
		Do G	uble-l desigi	lip sea	als					Laby S de	vrinth seals sign	'	Taconite seals ND design	N	+
Shaft d _a	Hou Dim A	ising iensi A ₁	ons H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Designations Housing complete with two seals	Components Housing	Seals	End cover
mm	mm										kg	-			
25	67	46	74	40	19	130	165	20	15	12	1,40	SNL 205 TG SNL 205 TC SNL 205 TS SNL 205 TND	SNL 205 SNL 505 SNL 205 SNL 205 SNL 205	TSN 205 G 2 FS 170 TSN 205 S TSN 205 ND	ASNH 506-605 ASNH 505 ASNH 506-605 ASNH 506-605
	77	52	89	50	22	150	185	20	15	12	1,90	SNL 305 TG SNL 305 TA SNL 305 TS SNL 305 TND	SNL 206-305 SNL 206-305 SNL 206-305 SNL 206-305	TSN 305 G TSN 305 A TSN 305 S TSN 305 ND	ASNH 507-606 ASNH 507-606 ASNH 507-606 ASNH 507-606
30	77	52	89	50	22	150	185	20	15	12	1,90	SNL 206 TG SNL 206 TA SNL 206 TC SNL 206 TS SNL 206 TND	SNL 206-305 SNL 206-305 SNL 506-605 SNL 206-305 SNL 206-305	TSN 206 G TSN 206 A 2 FS 170 TSN 206 S TSN 206 ND	ASNH 507-606 ASNH 507-606 ASNH 506-605 ASNH 507-606 ASNH 507-606
	82	52	93	50	22	150	185	20	15	12	2,20	SNL 306 TG SNL 306 TA SNL 306 TS SNL 306 TND	SNL 507-606 SNL 507-606 SNL 507-606 SNL 507-606	TSN 306 G TSN 306 A TSN 306 S TSN 306 ND	ASNH 507-606 ASNH 507-606 ASNH 507-606 ASNH 507-606
35	82	52	93	50	22	150	185	20	15	12	2,10	SNL 207 TG SNL 207 TA SNL 207 TC SNL 207 TS SNL 207 TND	SNL 207 SNL 207 SNL 507-606 SNL 207 SNL 207	TSN 207 G TSN 207 A 4 FS 170 TSN 207 S TSN 207 ND	ASNH 509 ASNH 509 ASNH 507-606 ASNH 509 ASNH 509
	85	60	108	60	25	170	205	20	15	12	2,75	SNL 307 TG SNL 307 TA SNL 307 TS SNL 307 TND	SNL 208-307 SNL 208-307 SNL 208-307 SNL 208-307	TSN 307 G TSN 307 A TSN 307 S TSN 307 ND	ASNH 510-608 ASNH 510-608 ASNH 510-608 ASNH 510-608
40	85	60	108	60	25	170	205	20	15	12	2,75	SNL 208 TG SNL 208 TA SNL 208 TC SNL 208 TS SNL 208 TND	SNL 208-307 SNL 208-307 SNL 508-607 SNL 208-307 SNL 208-307	TSN 208 G TSN 208 A 4 FS 170 TSN 208 S TSN 208 ND	ASNH 510-608 ASNH 510-608 ASNH 508-607 ASNH 510-608 ASNH 510-608
	90	60	113	60	25	170	205	20	15	12	3,20	SNL 308 TG SNL 308 TA SNL 308 TS SNL 308 TND	SNL 510-608 SNL 510-608 SNL 510-608 SNL 510-608	TSN 308 G TSN 308 A TSN 308 S TSN 308 ND	ASNH 510-608 ASNH 510-608 ASNH 510-608 ASNH 510-608

2 Recommendations

Page 10





Shaft	:	Beari seatir	ng ng	Width acros	S	Appropriate bearings an Self-aligning ball bearing	d locating rings	Self-aligning ball bearing	Locating rings
d _a	d _b	C_{a}	D_a	A ₂	A ₃	Spherical folier bearing	z per nousing	CARB bearing	2 per nousing
mm		mm		mm		_			
25	30	25	52	90	140	1205 E _	FRB 5/52 -	2205 E 22205 CC/W33 C 2205	FRB 3.5/52 FRB 3.5/52 FRB 3.5/52
	30	32	62	89	140	1305 E 21305 CC	FRB 7.5/62 FRB 7.5/62	2305 	FRB 4/62 - -
30	35	32	62	89	150	1206 E	FRB 8/62 -	2206 E 22206 CC/W33 C 2206	FRB 6/62 FRB 6/62 FRB 6/62
	35	34	72	94	155	1306 E 21306 CC	FRB 7.5/72 FRB 7.5/72	2306 -	FRB 3.5/72 -
35	45	34	72	96	160	1207 E	FRB 8.5/72 -	2207 E 22207 CC/W33 C 2207	FRB 5.5/72 FRB 5.5/72 FRB 5.5/72
	45	39	80	99	145	1307 E 21307 CC	FRB 9/80 FRB 9/80	2307 E _ _	FRB 4/80 _ _
40	50	39	80	99	160	1208 E _	FRB 10.5/80 -	2208 E 22208 E C 2208	FRB 8/80 FRB 8/80 FRB 8/80
	50	41	90	102	167	1308 E 21308 E	FRB 9/90 FRB 9/90	2308 E 22308 CC/W33	FRB 4/90 FRB 4/90

1 P	rodu	ct in	form	atio	n				2 Re	com	mendation	S	3 Produ	ct data	
Pag	е		. 3 C _a					F	Page)	10		SNL plu for bear d _a 45 –	mmer block l ings with cyl 60 mm	housings indrical bore
ĪŢ										a					
					P		1								
	D G	ouble desi	— A- e-lip s ign	eals					Lab S de	yrinth əsign	seals	Taconit ND des	e seals ign	Oil se U des	eals sign
Shaft d _a	Hou Dim A	sing ensio A ₁	ons H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Designations Housing complete with	Components Housing	Seals	End cover
mm	mm										kg	-	only		
45	85	60	109	60	25	170	205	20	15	12	2,75	SNL 209 TG SNL 209 TA SNL 209 TC SNL 209 TS SNL 209 TND	SNL 209 SNL 209 SNL 509 SNL 209 SNL 209 SNL 209	TSN 209 G TSN 209 A 4 FS 170 TSN 209 S TSN 209 ND	ASNH 511-609 ASNH 511-609 ASNH 509 ASNH 511-609 ASNH 511-609
	95	70	128	70	28	210	255	24	18	16	4,40	SNL 309 TG SNL 309 TA SNL 309 TS SNL 309 TND	SNL 511-609 SNL 511-609 SNL 511-609 SNL 511-609 SNL 511-609	TSN 309 G TSN 309 A TSN 309 S TSN 309 ND	ASNH 511-609 ASNH 511-609 ASNH 511-609 ASNH 511-609
50	90	60	113	60	25	170	205	20	15	12	3,00	SNL 210 TG SNL 210 TA SNL 210 TC SNL 210 TS SNL 210 TND	SNL 210 SNL 210 SNL 510-608 SNL 210 SNL 210	TSN 210 G TSN 210 A 4 FS 170 TSN 210 S TSN 210 ND	ASNH 512-610 ASNH 512-610 ASNH 510-608 ASNH 512-610 ASNH 512-610
	105	70	134	70	30	210	255	24	18	16	5,10	SNL 310 TG SNL 310 TA SNL 310 TS SNL 310 TND	SNL 512-610 SNL 512-610 SNL 512-610 SNL 512-610 SNL 512-610	TSN 310 G TSN 310 A TSN 310 S TSN 310 ND	ASNH 512-610 ASNH 512-610 ASNH 512-610 ASNH 512-610
55	95	70	128	70	28	210	255	24	18	16	4,20	SNL 211 TG SNL 211 TA SNL 211 TC SNL 211 TC SNL 211 TS SNL 211 TND	SNL 211 SNL 211 SNL 511-609 SNL 211 SNL 211	TSN 211 G TSN 211 A 4 FS 170 TSN 211 S TSN 211 ND	ASNH 513-611 ASNH 513-611 ASNH 511-609 ASNH 513-611 ASNH 513-611
	110	80	149	80	30	230	275	24	18	16	6,50	SNL 311 TG SNL 311 TA SNL 311 TS SNL 311 TS SNL 311 TND	SNL 513-611 SNL 513-611 SNL 513-611 SNL 513-611 SNL 513-611	TSN 311 G TSN 311 A TSN 311 S TSN 311 ND	ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 513-611 ASNH 513-611
60	105	70	134	70	30	210	255	24	18	16	4,75	SNL 212 TG SNL 212 TA SNL 212 TC SNL 212 TS SNL 212 TND	SNL 212 SNL 212 SNL 512-610 SNL 212 SNL 212	TSN 212 G TSN 212 A 4 FS 170 TSN 212 S TSN 212 ND	ASNH 515-612 ASNH 515-612 ASNH 512-610 ASNH 515-612 ASNH 515-612
	115	80	155	80	30	230	280	24	18	16	7,00	SNL 312 TG SNL 312 TA SNL 312 TS SNL 312 TND SNL 312 TURU	SNL 515-612 SNL 515-612 SNL 515-612 SNL 515-612 SNL 515-612 SNL 215 RU	TSN 312 G TSN 312 A TSN 312 S TSN 312 ND TSN 312 U	ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 515-612 ASNH 518-615 R

2 Recommendations

Page 10





Shaf	it	Bear seat	ing ing	Width acros	S		Appropriate bearings and Self-aligning ball bearing	d locating rings	Self-aligning ball bearing	Locating rings
d _a	d_b	C_{a}	D _a	A ₂	A ₃	A ₄	Spherical folier bearing	2 per nousing	CARB bearing	2 per nousing
mm		mm		mm			_			
45	55	30	85	97	160	-	1209 E -	FRB 5.5/85 _	2209 E 22209 CC/W33 C 2209	FRB 3.5/85 FRB 3.5/85 FRB 3.5/85
	55	44	100	107	172	_	1309 E 21309 E	FRB 9.5/100 FRB 9.5/100	2309 E 22309 CC/W33 -	FRB 4/100 FRB 4/100 –
50	60	41	90	102	165	-	1210 E	FRB 10.5/90 -	2210 E 22210 CC/W33 C 2210	FRB 9/90 FRB 9/90 FRB 9/90
	60	48	110	117	180		1310 E 21310 E	FRB 10.5/110 FRB 10.5/110	2310 22310 CC/W33 -	FRB 4/110 FRB 4/110 -
55	65	44	100	107	170	5	1211 E	FRB 11.5/100 -	2211 E 22211 E C 2211	FRB 9.5/100 FRB 9.5/100 FRB 9.5/100
	65	51	120	122	185	-	1311 E 21311 E	FRB 11/120 FRB 11/120	2311 22311 E -	FRB 4/120 FRB 4/120 –
60	70	48	110	117	185	_	1212 E _	FRB 13/110 -	2212 E 22212 E C 2212	FRB 10/110 FRB 10/110 FRB 10/110
	70	56	130	127	197	134	1312 21312 E	FRB 12.5/130 FRB 12.5/130	2312 22312 E	FRB 5/130 FRB 5/130

1 P	rodu	ct in	form	atior	n				2 Re	com	mendati	ons		3 Produc	t data	
Pag	e		. 3 Ca					F	Page		10			SNL plun for bearir d _a 65 – 8	n mer block h ngs with cyli 0 mm	nousings ndrical bore
							H 				A2-					
	C	ouble desi	e-lip s gn	eals					Laby S de	vrinth sign	seals		Tacor ND de	ite seals esign	Oil se U des	als iign
Shaft d _a	Hou Dim A	sing ensio A ₁	ons H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Designa Housing complet two seal	a tions e with s	Components Housing only	Seals	End cover
mm	mm										kg	_				
65	110	80	149	80	30	230	275	24	18	16	6,10	SNL 21: SNL 21: SNL 21: SNL 21: SNL 21: SNL 21:	B TG B TA B TC B TS B TND	SNL 213 SNL 213 SNL 513-611 SNL 213 SNL 213 SNL 213	TSN 213 G TSN 213 A 4 FS 170 TSN 213 S TSN 213 ND	ASNH 516-613 ASNH 516-613 ASNH 513-611 ASNH 516-613 ASNH 516-613
	120	90	177	95	32	260	315	28	22	20	9,50	SNL 31 SNL 31 SNL 31 SNL 31 SNL 31 SNL 31	B TG B TA B TS B TND B TURU	SNL 516-613 SNL 516-613 SNL 516-613 SNL 516-613 SNL 516-613 SNL 216 RU	TSN 313 G TSN 313 A TSN 313 S TSN 313 ND TSN 313 U	ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 516-613 ASNH 216 R
70	125	90	183	95	32	260	320	28	22	20	10,0	SNL 314 SNL 314 SNL 314 SNL 314 SNL 314 SNL 314	4 TG 4 TA 4 TS 4 TND 4 TURU	SNL 517 SNL 517 SNL 517 SNL 517 SNL 517 SNL 217 RU	TSN 314 G TSN 314 A TSN 314 S TSN 314 ND TSN 314 U	ASNH 517 ASNH 517 ASNH 517 ASNH 517 ASNH 517 ASNH 217 R
75	115	80	155	80	30	230	280	24	18	16	6,60	SNL 21 SNL 21 SNL 21 SNL 21 SNL 21 SNL 21	5 TG 5 TA 5 TC 5 TS 5 TND	SNL 215 SNL 215 SNL 515-612 SNL 215 SNL 215 SNL 215	TSN 215 G TSN 215 A 4 FS 170 TSN 215 S TSN 215 ND	ASNH 518-615 ASNH 518-615 ASNH 515-612 ASNH 518-615 ASNH 518-615
	140	100	194	100	35	290	345	28	22	20	12,5	SNL 31 SNL 31 SNL 31 SNL 31 SNL 31 SNL 31	5 TG 5 TA 5 TS 5 TND 5 TURU	SNL 518-615 SNL 518-615 SNL 518-615 SNL 518-615 SNL 518-615 SNL 218 RU	TSN 315 G TSN 315 A TSN 315 S TSN 315 ND TSN 315 U	ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 518-615 ASNH 218 R
80	120	90	177	95	32	260	315	28	22	20	9,00	SNL 210 SNL 210 SNL 210 SNL 210 SNL 210 SNL 210	6 TG 6 TA 6 TC 6 TS 6 TND	SNL 216 SNL 216 SNL 516-613 SNL 216 SNL 216 SNL 216	TSN 216 G TSN 216 A 4 FS 170 TSN 216 S TSN 216 ND	ASNH 216 ASNH 216 ASNH 516-613 ASNH 216 ASNH 216
	145	100	212	112	35	290	345	28	22	20	13,7	SNL 310 SNL 310 SNL 310 SNL 310 SNL 310 SNL 310	5 TG 5 TA 5 TS 5 TND 5 TURU	SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 SNL 519-616 RU	TSN 316 G TSN 316 A TSN 316 S TSN 316 ND TSN 316 U	ASNH 519-616 ASNH 519-616 ASNH 519-616 ASNH 519-616 ASNH 519-616 R

2 Recommendations

Page 10





Shaft	:	Bearii seatir	ng Ig	Width acros	s S		Appropriate bearings and Self-aligning ball bearing	d locating rings Locating rings	Self-aligning ball bearing	Locating rings
d _a	d _b	Ca	Da	A ₂	A ₃	A ₄	ophendarroller bearing	2 per nousing	CARB bearing	2 per nousing
mm		mm		mm			_			
65	75	51	120	128	190	-	1213 E -	FRB 14/120 -	2213 E 22213 CC/W33 C 2213	FRB 10/120 FRB 10/120 FRB 10/120
	75	58	140	138	200	141	1313 E 21313 E	FRB 12.5/140 FRB 12.5/140	2313 22313 E -	FRB 5/140 FRB 5/140 -
70	80	61	150	143	205	143	1314 21314 E	FRB 13/150 FRB 13/150	2314 22314 E C 2314	FRB 5/150 FRB 5/150 FRB 5/150
75	85	56	130	133	195		1215	FRB 15.5/130 –	2215 E 22215 E C 2215	FRB 12.5/130 FRB 12.5/130 FRB 12.5/130
	85	65	160	158	220	159	1315 21315 E	FRB 14/160 FRB 14/160	2315 22315 E C 2315	FRB 5/160 FRB 5/160 FRB 5/160
80	90	58	140	138	200	-	1216 -	FRB 16/140 -	2216 E 22216 E C 2216	FRB 12.5/140 FRB 12.5/140 FRB 12.5/140
	90	68	170	163	218	166	1316 21316 E	FRB 14.5/170 FRB 14.5/170	2316 22316 E C 2316	FRB 5/170 FRB 5/170 FRB 5/170

1 P	rodu	ct in	form	atio	n				2 Re	com	mendati	ons		3 Produc	t data	
Pag	e		. 3 C _a	∖_−				F	Dage		10			SNL plun for bearir d _a 85 – 1	nmer block h ngs with cyli 30 mm	nousings ndrical bore
D _a d _b							• H 1									
	D G	ouble desi	e-lip s gn	eals					Laby S de	yrinth esign	seals		Tacor ND d	nite seals esign	Oil se U des	als ign
Shaft d _a	Hou Dim A	sing ensic A ₁	ons H	H ₁	H ₂	J	L	N	N ₁	G	Mass	Designa Housing complet two seal	ations l e with ls	Components Housing only	Seals	End cover
mm	mm										kg	_				
85	125	90	183	95	32	260	320	28	22	20	9,50	SNL 21 SNL 21 SNL 21 SNL 21 SNL 21 SNL 21	7 TG 7 TA 7 TC 7 TS 7 TND	SNL 217 SNL 217 SNL 517 SNL 217 SNL 217 SNL 217	TSN 217 G TSN 217 A 4 FS 170 TSN 217 S TSN 217 ND	ASNH 217 ASNH 217 ASNH 517 ASNH 217 ASNH 217
	160	110	218	112	40	320	380	32	26	24	17,6	SNL 31 SNL 31 SNL 31 SNL 31 SNL 31 SNL 31	7 TG 7 TA 7 TS 7 TND 7 TURU	SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617 RU	TSN 317 G TSN 317 A TSN 317 S TSN 317 ND TSN 317 U	ASNH 520-617 ASNH 520-617 ASNH 520-617 ASNH 520-617 ASNH 520-617 R
90	140	100	194	100	35	290	345	28	22	20	11,8	SNL 218 SNL 218 SNL 218 SNL 218 SNL 218 SNL 218	8 TG 8 TA 8 TC 8 TS 8 TND	SNL 218 SNL 218 SNL 518-615 SNL 218 SNL 218	TSN 218 G TSN 218 A 4 FS 170 TSN 218 S TSN 218 ND	ASNH 218 ASNH 218 ASNH 518-615 ASNH 218 ASNH 218
95	175	120	242	125	45	350	410	32	26	24	22,0	SNL 319 SNL 319 SNL 319 SNL 319	9 TA 9 TS 9 TND 9 TURU	SNL 522-619 SNL 522-619 SNL 522-619 SNL 522-619 RU	TSN 319 A TSN 319 S TSN 319 ND TSN 319 U	ASNH 522-619 ASNH 522-619 ASNH 522-619 ASNH 522-619 R
100	160	110	218	112	40	320	380	32	26	24	17,6	SNL 220 SNL 220 SNL 220 SNL 220 SNL 220	0 TG 0 TA 0 TS 0 TND	SNL 520-617 SNL 520-617 SNL 520-617 SNL 520-617	TSN 220 G TSN 220 A TSN 220 S TSN 220 ND	ASNH 520-617 ASNH 520-617 ASNH 520-617 ASNH 520-617
	185	120	271	140	45	350	410	32	26	24	26,2	SNL 320 SNL 320 SNL 320 SNL 320	0 TA 0 TS 0 TND 0 TURU	SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 RU	TSN 320 A TSN 320 S TSN 320 ND TSN 320 U	ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620 R
110	175	120	242	125	45	350	410	32	26	24	22,0	SNL 222 SNL 222 SNL 222 SNL 222 SNL 222	2 TG 2 TA 2 TS 2 TND	SNL 522-619 SNL 522-619 SNL 522-619 SNL 522-619	TSN 222 G TSN 222 A TSN 222 S TSN 222 ND	ASNH 522-619 ASNH 522-619 ASNH 522-619 ASNH 522-619
120	185	120	271	140	45	350	410	32	26	24	26,2	SNL 224 SNL 224 SNL 224 SNL 224 SNL 224	4 TG 4 TA 4 TS 4 TND	SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620 SNL 524-620	TSN 224 G TSN 224 A TSN 224 S TSN 224 ND	ASNH 524-620 ASNH 524-620 ASNH 524-620 ASNH 524-620
130	190	130	290	150	50	380	445	35	28	24	33,0	SNL 220 SNL 220 SNL 220 SNL 220	6 TG 6 TA 6 TS 6 TND	SNL 526 SNL 526 SNL 526 SNL 526 SNL 526	TSN 226 G TSN 226 A TSN 226 S TSN 226 ND	ASNH 526 ASNH 526 ASNH 526 ASNH 526

2 Recommendations

Page 10

Page 3





Sha	ft	Bear seati	ing ng	Widtl acros	h SS		Appropriate bearings and loc Self-aligning ball bearing	ating rings Locating rings	Self-aligning ball bearing	Locating rings
d_a	d_{b}	C_{a}	Da	A ₂	A_3	A ₄	Spherical folier bearing	2 per nousing	CARB bearing	z per nousing
mm		mm		mm			-			
85	95	61	150	143	205	-	1217 _	FRB 16.5/150 -	2217 22217 E C 2217	FRB 12.5/150 FRB 12.5/150 FRB 12.5/150
	95	70	180	178	238	181	1317 21317 E	FRB 14.5/180 FRB 14.5/180	2317 22317 E C 2317	FRB 5/180 FRB 5/180 FRB 5/180
90	100	65	160	158	220	-	1218 22218 E	FRB 17.5/160 FRB 12.5/160	2218 23218 CC/W33 C 2218	FRB 12.5/160 FRB 6.25/160 FRB 12.5/160
95	110	80	200	191	253	195	1319 21319 E	FRB 17.5/200 FRB 17.5/200	2319 22319 E -	FRB 6.5/200 FRB 6.5/200 -
100	115	70	180	178	245	9	1220 22220 E	FRB 18/180 FRB 12/180	2220 23220 CC/W33 C 2220	FRB 12/180 FRB 4.85/180 FRB 12/180
	115	86	215	199	260	203	1320 21320 E	FRB 19.5/215 FRB 19.5/215	2320 22320 E C 2320	FRB 6.5/215 FRB 6.5/215 FRB 6.5/215
110	125	80	200	191	255	-	1222 22222 E	FRB 21/200 FRB 13.5/200	2222 23222 CC/W33 C 2222	FRB 13.5/200 FRB 5.1/200 FRB 13.5/200
120	135	86	215	199	270	-	1224 22224 E	FRB 22/215 FRB 14/215	– 23224 CC/W33 C 3224	– FRB 5/215 FRB 5/215
130	145	90	230	208	275	-	1226 22226 E	FRB 22/230 FRB 13/230	– 23226 CC/W33 C 2226	_ FRB 5/230 FRB 13/230



u _a	A	А ₁	п	п ₁	п ₂	J	L	IN	IN ₁	G		two seals	only	Seals	End cover
mm	mm										kg	-			
140	205	150	302	150	50	420	500	42	35	30	40,0	SNL 228 TG SNL 228 TA SNL 228 TS SNL 228 TND	SNL 528 SNL 528 SNL 528 SNL 528 SNL 528	TSN 228 G TSN 228 A TSN 228 S TSN 228 ND	ASNH 528 ASNH 528 ASNH 528 ASNH 528
150	220	160	323	160	60	450	530	42	35	30	49,0	SNL 230 TG SNL 230 TA SNL 230 TS SNL 230 TND	SNL 530 SNL 530 SNL 530 SNL 530 SNL 530	TSN 230 G TSN 230 A TSN 230 S TSN 230 ND	ASNH 530 ASNH 530 ASNH 530 ASNH 530
160	235	160	344	170	60	470	550	42	35	30	55,0	SNL 232 TG SNL 232 TA SNL 232 TS SNL 232 TS SNL 232 TND	SNL 532 SNL 532 SNL 532 SNL 532 SNL 532	TSN 232 G TSN 232 A TSN 232 S TSN 232 ND	ASNH 532 ASNH 532 ASNH 532 ASNH 532

•

2 Recommendations

Page 10

Page 3





Shaf	t	Bearing seating		Width across		Appropriate bearings a Spherical roller bearing	nd locating rings Locating rings	Spherical roller bearing	Locating rings
d _a	d_b	C_{a}	Da	A ₂	A ₃		z per housing	Units bearing	z per nousing
mm		mm		mm		-			
140	155	98	250	223	290	22228 CC/W33	FRB 15/250	23228 CC/W33 C 2228	FRB 5/250 FRB 15/250
150	165	106	270	241	310	22230 CC/W33	FRB 16.5/270	23230 CC/W33 C 2230	FRB 5/270 FRB 16.5/270
160	175	114	290	254	325	22232 CC/W33	FRB 17/290	23232 CC/W33 C 3232	FRB 5/290 FRB 5/290

1 Product information				2 Recomr	nendations	3 Product data			
Page	Page 3			Page	10	Sealing arrangements for SNL plummer block housings			
Housing s	eries 5								<u> </u>
Housing s	eries 2	Spl	sign G lit	Unsplit	Split	Felt strips Split	Unsplit	Design ND	End cover
Housing Size	Shaft dia- meter d _a , d _b	Seal sets Design G 2 double-lip seals	Design A 2 V-ring seals	Loose V-ring	Design C 2 felt strips	Loose felt strips	Design S 2 labyrinth seals	Design ND	End cover
_	mm	_							_
505	20 30	TSN 505 G -	TSN 505 A _	CR 400200 -	TSN 505 C -	2 × FS 170	2×TSN 505 S -	2 × TSN 505 ND -	ASNH 505
205	20 25 30 35	TSN 605 G TSN 506 G TSN 205 G -	TSN 605 A TSN 506 A 	CR 400200 CR 400250 - -	TSN 605 C TSN 506 C 	- 2×FS 170	2×TSN 605 S 2×TSN 506 S 2×TSN 205 S -	2 × TSN 605 ND 2 × TSN 506 ND 2 × TSN 205 ND -	ASNH 506-605
506-605	20 25 30 35	TSN 605 G TSN 506 G TSN 305 G -	TSN 605 A TSN 506 A TSN 305 A -	CR 400200 CR 400250 CR 400300 -	TSN 605 C TSN 506 C	- - 2 × FS 170	2×TSN 605 S 2×TSN 506 S 2×TSN 305 S -	2 × TSN 605 ND 2 × TSN 506 ND 2 × TSN 305 ND -	ASNH 506-605
206-305	25 30 35 45	TSN 606 G TSN 507 G TSN 206 G -	TSN 606 A TSN 507 A TSN 206 A -	CR 400250 CR 400300 CR 400350 -	TSN 606 C TSN 507 C 	- - 2 × FS 170	2×TSN 606 S 2×TSN 507 S 2×TSN 206 S -	2 × TSN 606 ND 2 × TSN 507 ND 2 × TSN 206 ND -	ASNH 507-606
507-606	25 30 35 45	TSN 606 G TSN 507 G TSN 306 G	TSN 606 A TSN 507 A TSN 306 A -	CR 400250 CR 400300 CR 400350 -	TSN 606 C TSN 507 C 	- - 2 × FS 170	2×TSN 606 S 2×TSN 507 S 2×TSN 306 S -	2 × TSN 606 ND 2 × TSN 507 ND 2 × TSN 306 ND -	ASNH 507-606
207	40 45 55	TSN 509 G TSN 207 G -	TSN 509 A TSN 207 A	CR 400400 CR 400450 -	TSN 509 C - -	_ _ 4 × FS 170	2×TSN 509 S 2×TSN 207 S -	2×TSN 509 ND 2×TSN 207 ND -	ASNH 509
508-607	30 35 50	TSN 607 G TSN 508 G -	TSN 607 A TSN 508 A -	CR 400300 CR 400350 -	TSN 607 C TSN 508 C -	_ _ 4 × FS 170	2×TSN 607 S 2×TSN 508 S -	2 × TSN 607 ND 2 × TSN 508 ND -	ASNH 508-607
208-307	35 45 50 60	TSN 608 G TSN 307 G TSN 208 G	TSN 608 A TSN 307 A TSN 208 A -	CR 400350 CR 400450 CR 400500 -	TSN 608 C 	_ _ 4 × FS 170	2×TSN 608 S 2×TSN 307 S 2×TSN 208 S -	2 × TSN 608 ND 2 × TSN 307 ND 2 × TSN 208 ND -	ASNH 510-608
509	40 45 55	TSN 509 G TSN 307 G -	TSN 509 A TSN 307 A -	CR 400400 CR 400450 -	TSN 509 C - -	_ _ 4 × FS 170	2×TSN 509 S 2×TSN 307 S -	2×TSN 509 ND 2×TSN 307 ND -	ASNH 509
209	40 50 55 65	TSN 609 G TSN 511 G TSN 209 G -	TSN 609 A TSN 511 A TSN 209 A -	CR 400400 CR 400500 CR 400550 -	TSN 609 C TSN 511 C 	_ _ 4 × FS 170	$\begin{array}{c} 2 \times TSN \ 609 \ S \\ 2 \times TSN \ 511 \ S \\ 2 \times TSN \ 209 \ S \\ - \end{array}$	2 × TSN 609 ND 2 × TSN 511 ND 2 × TSN 209 ND -	ASNH 511-609
510-608	35 45 50 60	TSN 608 G TSN 510 G TSN 308 G -	TSN 608 A TSN 510 A TSN 308 A -	CR 400350 CR 400450 CR 400500 -	TSN 608 C TSN 510 C 	- - 4 × FS 170	2×TSN 608 S 2×TSN 510 S 2×TSN 308 S	2×TSN 608 ND 2×TSN 510 ND 2×TSN 308 ND -	ASNH 510-608
Page 10

Page 3

3

Housing Size	Shaft dia- meter d _a , d _b	Seal sets Design G 2 double-lip seals	Design A 2 V-ring seals	Loose V-ring	Design C 2 felt strips	Loose felt strips	Design S 2 labyrinth seals	Design ND	End cover
	mm	_							_
210	45 55 60 70	TSN 610 G TSN 512 G TSN 210 G -	TSN 610 A TSN 512 A TSN 210 A -	CR 400450 CR 400550 CR 400600 -	TSN 610 C TSN 512 C - -	- - 4 × FS 170	2 × TSN 610 S 2 × TSN 512 S 2 × TSN 210 S -	2 × TSN 610 ND 2 × TSN 512 ND 2 × TSN 210 ND -	ASNH 512-610
511-609	40 50 55 65	TSN 609 G TSN 511 G TSN 309 G -	TSN 609 A TSN 511 A TSN 309 A -	CR 400400 CR 400500 CR 400550 -	TSN 609 C TSN 511 C - -	- - 4×FS 170	2 × TSN 609 S 2 × TSN 511 S 2 × TSN 309 S -	2 × TSN 609 ND 2 × TSN 511 ND 2 × TSN 309 ND -	ASNH 511-609
211	50 60 65 75	TSN 611 G TSN 513 G TSN 211 G -	TSN 611 A TSN 513 A TSN 211 A -	CR 400500 CR 400600 CR 400650 -	TSN 611 C TSN 513 C 	_ _ 4 × FS 170	$\begin{array}{c} 2\times TSN \ 611 \ S\\ 2\times TSN \ 513 \ S\\ 2\times TSN \ 211 \ S\\ -\end{array}$	2 × TSN 611 ND 2 × TSN 513 ND 2 × TSN 211 ND -	ASNH 513-611
512-610	45 55 60 70	TSN 610 G TSN 512 G TSN 310 G -	TSN 610 A TSN 512 A TSN 310 A -	CR 400450 CR 400550 CR 400600	TSN 610 C TSN 512 C 	_ _ 4 × FS 170	2×TSN 610 S 2×TSN 512 S 2×TSN 310 S -	2 × TSN 610 ND 2 × TSN 512 ND 2 × TSN 310 ND -	ASNH 512-610
212	55 65 70 85	TSN 612 G TSN 515 G TSN 212 G -	TSN 612 A TSN 515 A TSN 212 A -	CR 400550 CR 400650 CR 400700 -	TSN 612 C TSN 515 C - -	_ _ 4 × FS 170	$\begin{array}{c} 2\times TSN \ 612 \ S\\ 2\times TSN \ 515 \ S\\ 2\times TSN \ 212 \ S\\ -\end{array}$	2 × TSN 612 ND 2 × TSN 515 ND 2 × TSN 212 ND -	ASNH 515-612
513-611	50 60 65 75	TSN 611 G TSN 513 G TSN 311 G -	TSN 611 A TSN 513 A TSN 311 A	CR 400500 CR 400600 CR 400650 -	TSN 611 C TSN 513 C - -	_ _ 4 × FS 170	$\begin{array}{c} 2\times TSN \ 611 \ S\\ 2\times TSN \ 513 \ S\\ 2\times TSN \ 311 \ S\\ -\end{array}$	2 × TSN 611 ND 2 × TSN 513 ND 2 × TSN 311 ND -	ASNH 513-611
213	60 70 75 90	TSN 613 G TSN 516 G TSN 213 G -	TSN 613 A TSN 516 A TSN 213 A -	CR 400600 CR 400700 CR 400750 -	TSN 613 C TSN 516 C - -	_ _ 4 × FS 170	2×TSN 613 S 2×TSN 516 S 2×TSN 213 S -	2 × TSN 613 ND 2 × TSN 516 ND 2 × TSN 213 ND -	ASNH 516-613
515-612	55 65 70 85	TSN 612 G TSN 515 G TSN 312 G -	TSN 612 A TSN 515 A TSN 312 A -	CR 400550 CR 400650 CR 400700 -	TSN 612 C TSN 515 C - -	_ _ 4 × FS 170	$\begin{array}{c} 2\times TSN \ 612 \ S\\ 2\times TSN \ 515 \ S\\ 2\times TSN \ 312 \ S\\ -\end{array}$	2 × TSN 612 ND 2 × TSN 515 ND 2 × TSN 312 ND -	ASNH 515-612
215	65 80 85 100	TSN 615 G TSN 518 G TSN 215 G -	TSN 615 A TSN 518 A TSN 215 A -	CR 400650 CR 400800 CR 400850 -	TSN 615 C TSN 518 C - -	_ _ 4 × FS 170	2×TSN 615 S 2×TSN 518 S 2×TSN 215 S -	2 × TSN 615 ND 2 × TSN 518 ND 2 × TSN 215 ND -	ASNH 518-615
516-613	60 70 75 90	TSN 613 G TSN 516 G TSN 313 G -	TSN 613 A TSN 516 A TSN 313 A -	CR 400600 CR 400700 CR 400750 -	TSN 613 C TSN 516 C - -	- - 4 × FS 170	2 × TSN 613 S 2 × TSN 516 S 2 × TSN 313 S -	2 × TSN 613 ND 2 × TSN 516 ND 2 × TSN 313 ND -	ASNH 516-613

1 Product information				2 Recommendations			3 Product data			
Page 3				Page	10	Sealing arrangements for SNL plummer block housings				
Housing s	eries 5									
Housing series 2		De: Spl	Design G Split		Design C Split	Design C Felt strips Split	Design S Unsplit	Design ND	End cover	
Housing Size	Shaft dia- meter d _a , d _b	Seal sets Design G 2 double-lip seals	Design A 2 V-ring seals	Loose V-ring	Design C 2 felt strips	Loose felt strips	Design S 2 labyrinth seals	Design ND	End cover	
	mm	_							-	
216	90 105	TSN 216 G -	TSN 216 A _	CR 400900 -		- 4 × FS 170	2×TSN 216 S -	2 × TSN 216 ND -	ASNH 216	
517	75 80 95	TSN 517 G TSN 314 G -	TSN 517 A TSN 314 A -	CR 400750 CR 400800 -	TSN 517 C TSN 314 C -	- 4×FS 170	2 × TSN 517 S 2 × TSN 314 S -	2 × TSN 517 ND 2 × TSN 314 ND -	ASNH 517	
217	95	TSN 217 G	TSN 217 A	CR 400950	-	\mathbf{V}	$2 \times TSN 217 S$	$2 \times TSN 217 ND$	ASNH 217	
518-615	65 80 85 100	TSN 615 G TSN 518 G TSN 315 G -	TSN 615 A TSN 518 A TSN 315 A -	CR 400650 CR 400800 CR 400850	TSN 615 C TSN 518 C -	- - 4×FS 170	2 × TSN 615 S 2 × TSN 518 S 2 × TSN 315 S -	2 × TSN 615 ND 2 × TSN 518 ND 2 × TSN 315 ND -	ASNH 518-615	
218	100	TSN 218 G	TSN 218 A	CR 401000	-	-	$2 \times TSN 218 S$	$2 \times TSN 218 \text{ ND}$	ASNH 218	
519-616	70 85 90	TSN 616 G TSN 519 G TSN 316 G	TSN 616 A TSN 519 A TSN 316 A	CR 400700 CR 400850 CR 400900	TSN 616 C TSN 519 C -	_ _ _	$\begin{array}{c} 2\times TSN~616~S\\ 2\times TSN~519~S\\ 2\times TSN~316~S \end{array}$	2 × TSN 616 ND 2 × TSN 519 ND 2 × TSN 316 ND	ASNH 519-616	
520-617	75 90 95 115	TSN 617 G TSN 520 G TSN 317 G TSN 220 G	TSN 617 A TSN 520 A TSN 317 A TSN 220 A	CR 400750 CR 400900 CR 400950 CR 401100	TSN 617 C TSN 520 C - -	- - -	$\begin{array}{c} 2\times TSN~617~S\\ 2\times TSN~520~S\\ 2\times TSN~317~S\\ 2\times TSN~220~S \end{array}$	2 × TSN 617 ND 2 × TSN 520 ND 2 × TSN 317 ND 2 × TSN 220 ND	ASNH 520-617	
522-619	85 100 110 125	TSN 619 G TSN 522 G - TSN 222 G	TSN 619 A TSN 522 A TSN 319 A TSN 222 A	CR 400850 CR 401000 CR 401100 CR 401300	TSN 619 C TSN 522 C -	- - -	$\begin{array}{c} 2\times TSN \ 619 \ S\\ 2\times TSN \ 522 \ S\\ 2\times TSN \ 319 \ S\\ 2\times TSN \ 222 \ S\end{array}$	2 × TSN 619 ND 2 × TSN 522 ND 2 × TSN 319 ND 2 × TSN 222 ND	ASNH 522-619	
524-620	90 110 115 135	TSN 620 G TSN 524 G TSN 224 G	TSN 620 A TSN 524 A TSN 320 A TSN 224 A	CR 400900 CR 401100 CR 401100 CR 401300	TSN 620 C TSN 524 C - -	- - -	$\begin{array}{c} 2\times TSN \ 620 \ S \\ 2\times TSN \ 524 \ S \\ 2\times TSN \ 320 \ S \\ 2\times TSN \ 224 \ S \end{array}$	2 × TSN 620 ND 2 × TSN 524 ND 2 × TSN 320 ND 2 × TSN 224 ND	ASNH 524-620	
526	115 145	TSN 526 G TSN 226 G	TSN 526 A TSN 226 A	CR 401100 CR 401500	TSN 526 C -	-	$\begin{array}{c} 2 \times TSN \ 526 \ S \\ 2 \times TSN \ 226 \ S \end{array}$	2 × TSN 526 ND 2 × TSN 226 ND	ASNH 526	
528	125 155	TSN 528 G TSN 228 G	TSN 528 A TSN 228 A	CR 401300 CR 401500	TSN 528 C TSN 228 C	-	$\begin{array}{c} 2\times TSN \ 528 \ S \\ 2\times TSN \ 228 \ S \end{array}$	2 × TSN 528 ND 2 × TSN 228 ND	ASNH 528	
530	135 165	TSN 530 G TSN 230 G	TSN 530 A TSN 230 A	CR 401300 CR 401700	TSN 530 C -	-	2 × TSN 530 S 2 × TSN 230 S	2 × TSN 530 ND 2 × TSN 230 ND	ASNH 530	
532	140 175	TSN 532 G TSN 232 G	TSN 532 A TSN 232 A	CR 401400 CR 401700	TSN 532 C -	-	2 × TSN 532 S 2 × TSN 232 S	2 × TSN 532 ND 2 × TSN 232 ND	ASNH 532	

www.ageritechniek.e

Other products for trouble-free operation

Robust, high-performance standard bearings

SKF produces the self-aligning ball bearings, spherical roller bearings and CARB bearings normally incorporated in SNL plummer block housings in many sizes and several designs. All three bearing types are self-aligning. The degree of misalignment which can be accommodated depends on the bearing series and also on the seals used in the SNL housings.

The self-aligning ball bearings and spherical roller bearings can be used for both locating and non-locating bearing arrangements. At non-locating positions, the bearing outer ring is free to move axially in its seating in the housing bore. CARB bearings, on the other hand, accommodate axial displacements within the bearing and are always non-locating. It is usual to combine a CARB bearing at the nonlocating side with a spherical roller bearing arranged as a locating bearing at the other side.

Self-aligning ball bearings

Series 12, 22, 13 and 23 self-aligning ball bearings can be incorporated in SNL plummer block housings. Sealed self-aligning ball bearings of series 22-2RS1 are also appropriate, particularly where the surroundings in which the plummer blocks are to operate are heavily contaminated. Self-aligning ball bearings are available with tapered bore for mounting on adapter sleeves or with cylindrical bore.

Spherical roller bearings

The spherical roller bearings which can be used in SKF plummer block housings of the SNL design are those of series 222, 232, 213 and 223. The bearings are available with tapered bore for mounting on adapter or withdrawal sleeves, or with cylindrical bore. Sealed spherical roller bearings of ISO Dimension Series 22 can also be incorporated.

CARB bearings

These bearings are a more recent addition to the range of ball and roller bearings offered by SKF and are an SKF invention. CARB bearings of series C 22, C 23 and C 32 can be incorporated in SNL plummer block housings.

Although available in a caged as well as a full complement version, it is normally recommended that caged bearings are used in SNL housings. CARB bearings are available with a tapered bore for mounting on an adapter sleeve or a withdrawal sleeve, as well as with a cylindrical bore.

For easy mounting – adapter and withdrawal sleeves

Generally the bearings with a tapered bore incorporated in SNL plummer block housings are mounted on smooth or stepped shafts with the aid of an adapter sleeve or, on stepped shafts only, a withdrawal sleeve. These sleeves are produced by SKF in appropriate sizes for the range of bearings which can be used in SNL housings. The adapter sleeves are the more popular as they are more versatile and are easier to mount.

Adapter sleeves

These are slotted sleeves with a tapered outside diameter. The sizes used with bearings for SNL housings have an external taper of 1:12 and are supplied complete with lock nut and locking washer. Their dimensions are in accordance with ISO 2982-1:1995.

When using adapter sleeves on smooth shafts it is possible to locate the bearing at any position on the shaft and no additional axial location is required.

Withdrawal sleeves

These are also slotted sleeves with a tapered outside diameter. The sizes used with bearings for SNL housings have an external taper of 1:12. Their dimensions are in accordance with ISO 2982-1:1995.

Bearings on withdrawal sleeves must be mounted against a fixed abutment, e.g. a shaft shoulder. The withdrawal sleeve must be secured in position after it has been pressed into the bearing bore by a lock nut or end plate on the shaft. The nuts are not supplied with the sleeves. More information about

- self-aligning ball bearings and spherical roller bearings
 (→ General Catalogue 4000 and brochure 5100)
- CARB bearings (\rightarrow brochure 5102)
- adapter and withdrawal sleeves
 (→ catalogue 3766)

Other products

Lock nuts

SKF lock nuts, also referred to as shaft nuts, are available in several designs to axially locate bearings on shaft ends. The most popular are those of series KM, KML and HM. These nuts have four or eight equally spaced slots in the outside diameter and are locked in position with locking washers or locking clips engaging a groove in the shaft. The nut dimensions are in accordance with ISO 2982-2:1995 as are the dimensions of the series MB and MBL locking washers and MS locking clips.

Other lock nuts produced by SKF include those of series KMT, KMTA, KMK and KMFE, that do not require a groove in the shaft.



Lubricating greases for bearings

Lubrication is a necessity for proper bearing performance. Grease is normally used for applications involving SNL plummer blocks. SKF has put considerable effort into establishing a range of high-quality greases for ball and roller bearing lubrication.

The SKF SYSTEM 24 automatic lubricator can also be used with SNL plummer block housings. An adapter can be fitted to the standard drilled and tapped hole in the housing cap. It should be remembered that surplus grease should be able to leave the housing.



SKF ConCentra roller bearing units These units are plummer blocks with ready-lubricated bearings for easy installation. They comprise

- a one-piece plummer block housing of grey cast iron,
- a spherical roller bearing of series 222 with special inner ring,
- a special adapter sleeve, and
- two seals of nitrile rubber double lip type or two labyrinth seals.

The units are available in a locating and a non-locating version.

Other bearing housings

To meet a wide variety of application demands, SKF produces a comprehensive range of bearing housings. The majority of these are of the split plummer block type but the SKF range also includes

- · one-piece plummer block housings,
- flanged housings,
- take-up housings, and
- two-bearing housings.

Most of these housings are designed to take self-aligning bearings, and the range extends to shaft diameters up to and including 1 800 mm. Housings are available for oil lubrication as well as grease lubrication and also for bearings with cylindrical bore or with tapered bore, mounted on adapter or withdrawal sleeves. Smooth or stepped shafts can be used.

Various different types of seal are used. Most housings are made of grey cast iron but spheroidal graphite cast iron or cast steel housings are included in the range.

For further information, please contact SKF.

More information about

- lock nuts (→ brochure 4412 and catalogue 3766)
- greases (→ catalogue MP3000)
 - ConCentra roller bearing units (→ brochure 5103)
 - housings (→ catalogue 4005)



Condition monitoring equipment

The goals of condition monitoring are to maximise the time that the machine is functioning well and to minimise the number of breakdowns, thereby significantly reducing operating downtime and maintenance costs.

To achieve this, it is recommended that the bearing and machine condition be monitored either periodically or continuously. Condition monitoring enables incipient bearing damage to be detected and evaluated, so that bearing replacement can be scheduled for a time when the machine is not in operation, to avoid unplanned stoppages. Applied to all machinery (not just sensitive or problematic machines), condition monitoring improves machinery operation to an optimum level, often exceeding the original equipment specifications.

SKF provides a comprehensive range of condition monitoring equipment to measure all important parameters. These include

- temperature,
- speed,
- noise,
- oil condition,
- shaft alignment,
- vibration and
- bearing condition.

The range includes lightweight, handheld devices for manual use as well as complex continuous monitoring systems for fixed installations in connection with preventive maintenance.

One example is the Machine Reliability Inspection System MARLIN[™] which is at the leading edge of technology and allows storage of up to 2 000 measuring points. It can be used to diagnose machines and individual bearings and is backed by tailored software for the evaluation of the readings including enveloping vibration acceleration curves.



Recording vibration values using an SKF Microlog data collection unit

Taking the temperature



Noise testing



The MARLIN™ machine reliability inspection system



www.lageritechniek.e

The SKF Group – a worldwide corporation

SKF is an international industrial Group operating in some 130 countries and is world leader in bearings.

The company was founded in 1907 following the invention of the self-aligning ball bearing by Sven Wingquist and, after only a few years, SKF began to expand all over the world.

Today, SKF has some 45 000 employees and around 80 manufacturing facilities spread throughout the world. An international sales network includes a large number of sales companies and some 7 000 distributors and retailers. Worldwide availability of SKF products is supported by a comprehensive technical advisory service.

The key to success has been a consistent emphasis on maintaining the highest quality of its products and services. Continuous investment in research and development has also played a vital role, resulting in many examples of epoch-making innovations.

The business of the Group consists of bearings, seals, special steel and a comprehensive range of other hightech industrial components. The experience gained in these various fields provides SKF with the essential knowledge and expertise required in order to provide the customers with the most advanced engineering products and efficient service.



The SKF Group is the first major bearing manufacturer to have been granted approval according to ISO 14001, the international standard for environmental management systems. The certificate is the most comprehensive of its kind and covers more than 60 SKF production units in 17 countries.



The SKF Engineering & Research Centre is situated just outside Utrecht in The Netherlands. In an area of 17 000 square metres (185 000 sq.ft) some 150 scientists, engineers and support staff are engaged in the further improvement of bearing performance. They are developing technologies aimed at achieving better materials, better designs, better lubricants and better seals – together leading to an even better understanding of the operation of a bearing in its application. This is also where the SKF Life Theory was evolved, enabling the design of bearings which are even more compact and offer even longer operational life.



SKF has developed the Channel concept in factories all over the world. This drastically reduces the lead time from raw material to end product as well as work in progress and finished goods in stock. The concept enables faster and smoother information flow, eliminates bottlenecks and bypasses unnecessary steps in production. The Channel team members have the knowledge and commitment needed to share the responsibility for fulfilling objectives in areas such as quality, delivery time, production flow etc.



SKF manufactures ball bearings, roller bearings and plain bearings. The smallest are just a few millimetres (a fraction of an inch) in diameter, the largest several metres. SKF also manufactures bearing and oil seals which prevent dirt from entering and lubricant from leaking out. SKF's subsidiaries CR and RFT S.p.A. are among the world's largest producers of seals.



® SKF and CARB are registered trademarks of SKF.

© Copyright SKF 2002

The contents of this publication are the copyright of the publisher and may not be reproduced (even extracts) unless permission is granted. Every care has been taken to ensure the accuracy of the information contained in this publication but no liability can be accepted for any loss or damage whether direct, indirect or consequential arising out of the use of the information contained herein.

Publication 4403/III E · January 2002

Printed in Sweden on environmentally friendly, chlorine-free paper (Multiart Silk) by Hyltebruks Tryckeri AB.